


Most - Often - Needed

1966

Volume R-26

RADIO
DIAGRAMS
and Servicing Information



Compiled by
M. N. BEITMAN

SUPREME PUBLICATIONS

Supreme Publications for Faster Radio-Television Repairs

COVERS ALL POPULAR SETS

Here is your service data for faster, easier TV repairs. Lowest priced. Best by comparison. *Supreme TV* manuals have all needed service material on every popular TV set. Helpful, practical, factory-prepared data that will really make TV servicing easy for you. Benefit and save with these amazing values in service manuals. Only \$3 per large volume. Used by 184,000 wise servicemen for faster repairs. Join them; begin to make TV repairs easily.

Most - Often - Needed

1963

Television

Servicing Information



The repair of any TV set is simple with **Supreme Television** service manuals. Every set is covered in a practical manner to simplify trouble-shooting and repair. With this help find toughest faults in a jiffy. Most \$3 TV volumes cover a whole year.



RADIO Manuals

Your best source for all needed RADIO diagrams and service data. Covers everything from most recent 1966 radios to pre-war old-timers; home radios, stereo, combinations, transistor portables, FM. Every manual has large schematics, all needed alignment facts, printed boards, voltages, trimmers, dial stringing, and hints. Volumes are big, 8½x11 inches, about 190 pages. See coupon at right for list of **SUPREME** popular radio service manuals ►

—NO-RISK ORDER COUPON—

TELEVISION SERVICE MANUALS

Supreme TV manuals are best for faster, easier TV repairs. Lowest priced. Factory data on practically all sets. Complete circuits, all needed alignment facts, wiring board views, waveforms, voltages, production changes, and double-page schematics. Only \$3 per large annual manual. Check volumes wanted,

- ☐ New 1966 Television Manual, \$3. ☐ 1963 TV, \$3.
- ☐ Additional 1965 TV, \$3. ☐ Early 1965 TV, \$3.
- ☐ New 1964 Television Manual, \$3. ☐ 1963 TV, \$3.
- ☐ Additional 1962 TV, \$3. ☐ Early 1962 TV, \$3.
- ☐ 1961 TV Manual, \$3. ☐ 1960 TV Manual, \$3.
- ☐ Additional 1959 TV, \$3. ☐ Early 1959 TV, \$3.
- ☐ 1958 TV Manual, \$3. ☐ Additional 1957 TV, \$3.
- ☐ Early 1957 Television, \$3. ☐ 1956 TV Manual, \$3.
- ☐ Additional 1955 TV, \$3. ☐ Early 1955 TV, \$3.
- ☐ 1954 TV, \$3. ☐ Master Index to all Manuals, 25¢

RADIO DIAGRAM MANUALS

Here are low-priced radio manuals that simplify repairing. Cover everything from most recent 1966 radios to pre-war old-timers; home radios, stereo, combinations, transistor portables, FM, and auto sets. Large schematics, all needed alignment facts, printed boards, voltages, dial stringing, hints. Volumes are big, 8½ x 11", about 190 pages, each.

\$2⁵⁰

- ☐ 1985, ☐ 1964 Manual, only \$2.50
- ☐ 1963, ☐ 1962, ☐ 1961, ☐ 1960, ☐ 1959, ☐ 1958,
- ☐ 1957, ☐ 1956, ☐ 1955, ☐ 1954, ☐ 1953, ☐ 1952,
- ☐ 1951, ☐ 1950, ☐ 1949, ☐ 1946, ☐ 1947, ☐ 1946,
- ☐ 1942, ☐ 1941, ☐ 1940, ☐ 1926-36, EACH, \$2.50
- ☐ Auto Radio 1964-65 Diagram Manual, \$2.50

SUPREME PUBLICATIONS

1760 Balsam Road, Highland Park, ILL.


Rush today **TV** and **Radio** manuals checked in no-risk order form of this ad. Send postpaid, I am enclosing full price. You guarantee my complete satisfaction or my money back.

Name: _____


Address: _____

Admiral



Chassis 8K4, Models YD201GP, A, YD202GP, A





COMPONENT CONNECTIONS TO BACK OF BOARD AND WIRING



PRECISION WIRED SYSTEM 2014B377-3




COMMON PRECISION WIRED GROUND.
IF=455KC UNLESS OTHERWISE SPECIFIED:
CAPACITOR VALUES IN MICROFARADS AND
RESISTOR VALUES IN OHMS 1/4WAT, 10%
VOLTAGE AND CURRENT READINGS TAKEN
WITH FRESH BATTERY, NO SIGNAL,
VOLUME CONTROL AT MINIMUM.
CURRENT DRAIN=13MA






POSITION BATTERY IN FRONT
SECTION OF CASE SO THAT
SNAPS ON BATTERY MATE WITH
SNAPS ON BATTERY CLIP.

**BATTERY CLIP WITH
SNAP FASTENERS.**





Admiral®

Chassis 10J1, Model YD257



AC CHARGER OPERATION


Plug the AC Charger into the jack on the radio and into a wall outlet and the radio operates from ordinary AC house current—little battery drain. After using radio outdoors (from battery), plug in the AC charger with radio turned "OFF" and the AC Charger will restore power to the radio battery. The AC Charger will extend the useful life of the transistor radio battery many times its normal expectancy.



COMPONENT & ALIGNMENT LOCATIONS, TOP VIEW

Admiral

Chassis 2B2, Models YG1027,
YG1029, YG1037, YG1047, YG1057




NOTES:

ALL RESISTOR VALUES IN OHMS AND CAPACITOR VALUES IN MICROFARADS UNLESS OTHERWISE SHOWN. ALL VOLTAGES TAKEN WITH A VACUUM TUBE VOLTMETER WITH RESPECT TO COMMON B- COMMON B- CHASSIS GROUND


⚡ DENOTES FRAME OF CONTROL IS GROUND TO CHASSIS.

NEEDLE REPLACEMENT

Turn Needle Selector handle so that desired needle number ("LP" or "78") faces up. Corresponding needle will be pointing down. Loosen screw at base of needle assembly and slide assembly forward and remove from cartridge. To install new needle assembly, slide lugs of assembly under screw and tighten securely. Needle shaft must rest in centering notch. Be sure new needles are mounted to correct sides of turn-over cartridge.




VIEW OF CHASSIS SHOWING COMPONENTS



CHASSIS REMOVAL

1. Remove the four turntable hold-down screws.
2. Raise turntable front edge for access to chassis.
3. For chassis removal: Pull off knobs.
4. Remove the nuts on the tone and loudness shafts, while supporting escutcheon.
5. Set escutcheon and control cups off.
6. Pull "plug-in" wire connectors to chassis off.
7. Remove chassis.



MODEL IDENTIFICATION CHART

MODEL	FINISH	RECORD CHANGER	CHASSIS
YG1571	Walnut	RC7F5M-71AN or RC7W5Q-71AN or RC7W5Q-87AN	22C5A
YG8001	Walnut	RC7F4E-70AN	*20C5
YG8002	Mahogany		
YG8001M	Walnut	RC7W4N-94AN or RC7W4N-70AN	
YG8002M	Mahogany		
YG8011	Walnut	RC7F4E-70AN	22C5
YG8012	Mahogany		
YG8025	Maple		
YG8031	Walnut	RC7F4F-87AN or RC7F4F-71AN	
YG8045	Maple		
YG8051	Walnut		
YG8061	Walnut		
YG8075	Maple		
YG8011M	Walnut	RC7W4N-94AN or RC7W4N-70AN	22C5
YG8012M	Mahogany		
YG8025M	Maple	RC7W4N-70AN or RC7W4N-86AN	
YG8031M	Walnut	RC7W4P-87AN or RC7W4P-71AN	
YG8045M	Maple		
YG8051M	Walnut		
YG8061M	Walnut		
YG8075M	Maple		
Radio Information for the Following Stereo Theater Models			
SMG3001	Walnut	RC7F4F-71AN or RC7F4F-87AN	22C5
SMG3002	Mahogany		
SMG3701	Walnut	RC7W4P-71AN or RC7W4P-87AN	22C5A
SMG3705	Maple		
SMG3711	Walnut		
SRG2201	Walnut	RC7W4P-71AN or RC7W4P-87AN	*20C5A
SMG2201	Walnut		
SMG2205	Maple		22C5A

*FM-AM, no provisions for FM Stereo

GENERAL

Model YG1571 is a table or wall mount unit, while the others are console models of walnut, mahogany or maple finish. An 11" turntable, 4-speed automatic phonograph with a complete system shut-off is used in each model.


The various chassis are completely transistorized and are in one unit. The chassis are basically identical except that the 20C5 and 20C5A chassis do not have FM stereo circuits. No provisions are available for adding this service to the 20C5 and 20C5A chassis. The 22C5 and 22C5A chassis include the necessary circuitry for FM stereo.

The FM and AM, RF and IF sections are all on one precision wired board. FM Stereo and stereo audio circuits are on a second precision wired board. The FM circuit consists of RF, mixer, oscillator, three IF and a ratio detector stage. The AM consists of an auto-dyne converter, two IF and a diode detector stage. The FM stereo section consists of a 19KC amplifier, 38KC doubler, indicator control stage, and four diodes for FM Stereo detection. Six transistors are used for each stereo audio amplifier section. Attenuator type bass and treble controls along with loudness and balance controls are part of each stereo amplifier. The last three stages are direct coupled for both AC and DC current. Negative feedback is provided from the output to the base of the predriver. The output circuit is complementary symmetry type.


Chassis 22C5, A, 20C5, A

Circuit diagram on pages 8 and 9;
other service material on page 10.

SPEAKER WIRING SCHEMATICS




SPEAKER WIRING FOR 'G8031 & M, 45 & M, 51 & M, 61 & M, 75 & M.



SPEAKER WIRING FOR YG1571, YG800 & M, YG8010 & M, YG8020 & M SERIES.

Admiral


Chassis 22C5, A, Schematic Diagram
(Chassis 20C5, A, are similar less FM stereo)




ADMIRAL Chassis 22C5,A, Schematic Diagram, Continued




ADMIRAL Chassis 20C5, A, 22C5, A, Service Information, Continued




Top View of FM-AM, RF & IF Section



Bottom View of FM-AM, RF & IF Section



Top View of FM Stereo and Stereo Amp Section




Bottom View of FM Stereo and Stereo Amp Section

Admiral


Chassis 4E4

Models YG1507, YG1527, YG1531



CHASSIS REMOVAL

1. Remove the four turntable hold-down screws.
2. Raise turntable front edge for access to chassis.
3. For chassis removal: Pull of knobs.
4. Remove the nuts on the tone and loudness shafts, while supporting escutcheon.
5. Set escutcheon and control cups off.
6. Pull "plug-in" wire connectors to chassis off.
7. Remove chassis.



Admiral

MODEL CHART

MODEL	NAME	FINISH	CHASSIS
YG827	Kimberly	Tan	5V6A
YG829	Kimberly	Charcoal	
YG837	Dunbar	Brown	5V6
YG839	Dunbar	Charcoal	
YG841	Aurora	Walnut	5V6A
YG851	Galaxy	Walnut	
YG861	Golden Classic	Walnut	5W6

(For circuit diagram see next page, directly at right)




YG830 SERIES


SERVICE HINT

Severe hum on these chassis can be caused by a breakdown of the Output Transistor Q5, No. 57C6-14. Should this be encountered, replace the transistor and change R19, 24 ohm, 1/2 watt resistor to 36 ohm 1/2 watt for increased reliability.


When servicing the chassis for other reasons, R19 should be changed to 36 ohms to avoid the possibility of damaging Q5. Some chassis will already have this change.




TOP VIEW OF CHASSIS SHOWING ALIGNMENT POINTS AND COMPONENTS



DIAL STRINGING DIAGRAM, 5W6





BOTTOM VIEW OF CHASSIS



DIAL STRINGING DIAGRAM, 5V6, 5V6A

ADMIRAL Chassis 5V6, 5V6A, 5W6, Schematic Diagram, Continued





Admiral

Chassis 12H1
Model YG171

PRECISION WIRED SYSTEM 20148377-14

2SA102AA
CONVERTER
Q1

2SA101A
1st IF
Q2

2SA101BAorBB
2nd IF
Q3

0A-90
DET-AVC
Q4

2SB175A
1st AF AMP
Q5

2SB175A
2nd AF AMP
Q6

2SB175A
DRIVER
Q7

2SB172A
OUTPUT
Q8

2SB172A
OUTPUT
Q9

COMMON PRECISION WIRED GROUND.
IF=455KC. UNLESS OTHERWISE SPECIFIED
CAPACITOR VALUES IN MICROFARADS;
RESISTOR VALUES IN OHMS I/AWATT, 10%
VOLTAGE AND CURRENT READINGS TAKEN
WITH FRESH BATTERY, NO SIGNAL,
VOLUME CONTROL AT MINIMUM.
CURRENT DRAIN=18MA.

NOT MOUNTED ON CIRCUIT BOARD.
VOLTAGES TAKEN WITH VTVM BETWEEN
POINTS INDICATED AND COMMON
GROUND (POSITIVE).

COMPONENTS:
R1 5.6K, R2 10K, R3 1.8K, R4 5.6K, R5 47K, R6 390, R7 56K, R8 6.8K, R9 10K, R10 330, R12 5K, R13 3.9K, R14 3.3K, R16 330, R17 3.9K, R18 100K, R19 220K, R20 50, R21 820, R22 100, R23 470K, R24 330.
C1 .0047, C2 .0047, C3 30 3V, C4 5PF, C5 .02, C6 0.033, C7 5 6V, C8 .01 50V, C9 3PF, C10 30 3V, C12A, C12B.
L1, L2, L3, L4, L5, L6, L7.
S1 ON-OFF SWITCH PART OF R12.
M1 PM SPEAKER, M2 EARPHONE JACK.

TRANSISTORS:
Q1 2SA102AA, Q2 2SA101A, Q3 2SA101BAorBB, Q4 0A-90, Q5 2SB175A, Q6 2SB175A, Q7 2SB175A, Q8 2SB172A, Q9 2SB172A.

DIODES:
D1 (DET-AVC), D2 (AFC).

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

VOLTAGE READINGS:
Q1: -2.2V, -0.75V, -0.7V.
Q2: -0.3V, -0.12V.
Q3: -1.05V, -0.9V.
Q4: -0.9V.
Q5: -1.6V, -0.16V, -0.12V.
Q6: -0.03V, -0.15V.
Q7: 0V.
Q8: -0.17V, 0V, -0.17V.
Q9: -0.17V, 0V, -0.17V.

RESISTOR VALUES:
R1 5.6K, R2 10K, R3 1.8K, R4 5.6K, R5 47K, R6 390, R7 56K, R8 6.8K, R9 10K, R10 330, R12 5K, R13 3.9K, R14 3.3K, R16 330, R17 3.9K, R18 100K, R19 220K, R20 50, R21 820, R22 100, R23 470K, R24 330.

CAPACITOR VALUES:
C1 .0047, C2 .0047, C3 30 3V, C4 5PF, C5 .02, C6 0.033, C7 5 6V, C8 .01 50V, C9 3PF, C10 30 3V, C12A, C12B.

INDUCTORS:
L1, L2, L3, L4, L5, L6, L7.

SWITCHES:
S1 ON-OFF SWITCH PART OF R12.

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

DIODES:
D1 (DET-AVC), D2 (AFC).

TRANSISTORS:
Q1 2SA102AA, Q2 2SA101A, Q3 2SA101BAorBB, Q4 0A-90, Q5 2SB175A, Q6 2SB175A, Q7 2SB175A, Q8 2SB172A, Q9 2SB172A.

DIODES:
D1 (DET-AVC), D2 (AFC).

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

VOLTAGE READINGS:
Q1: -2.2V, -0.75V, -0.7V.
Q2: -0.3V, -0.12V.
Q3: -1.05V, -0.9V.
Q4: -0.9V.
Q5: -1.6V, -0.16V, -0.12V.
Q6: -0.03V, -0.15V.
Q7: 0V.
Q8: -0.17V, 0V, -0.17V.
Q9: -0.17V, 0V, -0.17V.

RESISTOR VALUES:
R1 5.6K, R2 10K, R3 1.8K, R4 5.6K, R5 47K, R6 390, R7 56K, R8 6.8K, R9 10K, R10 330, R12 5K, R13 3.9K, R14 3.3K, R16 330, R17 3.9K, R18 100K, R19 220K, R20 50, R21 820, R22 100, R23 470K, R24 330.

CAPACITOR VALUES:
C1 .0047, C2 .0047, C3 30 3V, C4 5PF, C5 .02, C6 0.033, C7 5 6V, C8 .01 50V, C9 3PF, C10 30 3V, C12A, C12B.

INDUCTORS:
L1, L2, L3, L4, L5, L6, L7.

SWITCHES:
S1 ON-OFF SWITCH PART OF R12.

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

DIODES:
D1 (DET-AVC), D2 (AFC).

TRANSISTORS:
Q1 2SA102AA, Q2 2SA101A, Q3 2SA101BAorBB, Q4 0A-90, Q5 2SB175A, Q6 2SB175A, Q7 2SB175A, Q8 2SB172A, Q9 2SB172A.

DIODES:
D1 (DET-AVC), D2 (AFC).

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

VOLTAGE READINGS:
Q1: -2.2V, -0.75V, -0.7V.
Q2: -0.3V, -0.12V.
Q3: -1.05V, -0.9V.
Q4: -0.9V.
Q5: -1.6V, -0.16V, -0.12V.
Q6: -0.03V, -0.15V.
Q7: 0V.
Q8: -0.17V, 0V, -0.17V.
Q9: -0.17V, 0V, -0.17V.

RESISTOR VALUES:
R1 5.6K, R2 10K, R3 1.8K, R4 5.6K, R5 47K, R6 390, R7 56K, R8 6.8K, R9 10K, R10 330, R12 5K, R13 3.9K, R14 3.3K, R16 330, R17 3.9K, R18 100K, R19 220K, R20 50, R21 820, R22 100, R23 470K, R24 330.

CAPACITOR VALUES:
C1 .0047, C2 .0047, C3 30 3V, C4 5PF, C5 .02, C6 0.033, C7 5 6V, C8 .01 50V, C9 3PF, C10 30 3V, C12A, C12B.

INDUCTORS:
L1, L2, L3, L4, L5, L6, L7.

SWITCHES:
S1 ON-OFF SWITCH PART OF R12.

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

DIODES:
D1 (DET-AVC), D2 (AFC).

TRANSISTORS:
Q1 2SA102AA, Q2 2SA101A, Q3 2SA101BAorBB, Q4 0A-90, Q5 2SB175A, Q6 2SB175A, Q7 2SB175A, Q8 2SB172A, Q9 2SB172A.

DIODES:
D1 (DET-AVC), D2 (AFC).

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

VOLTAGE READINGS:
Q1: -2.2V, -0.75V, -0.7V.
Q2: -0.3V, -0.12V.
Q3: -1.05V, -0.9V.
Q4: -0.9V.
Q5: -1.6V, -0.16V, -0.12V.
Q6: -0.03V, -0.15V.
Q7: 0V.
Q8: -0.17V, 0V, -0.17V.
Q9: -0.17V, 0V, -0.17V.

RESISTOR VALUES:
R1 5.6K, R2 10K, R3 1.8K, R4 5.6K, R5 47K, R6 390, R7 56K, R8 6.8K, R9 10K, R10 330, R12 5K, R13 3.9K, R14 3.3K, R16 330, R17 3.9K, R18 100K, R19 220K, R20 50, R21 820, R22 100, R23 470K, R24 330.

CAPACITOR VALUES:
C1 .0047, C2 .0047, C3 30 3V, C4 5PF, C5 .02, C6 0.033, C7 5 6V, C8 .01 50V, C9 3PF, C10 30 3V, C12A, C12B.

INDUCTORS:
L1, L2, L3, L4, L5, L6, L7.


SWITCHES:
S1 ON-OFF SWITCH PART OF R12.

OTHER:
F1 FERRITE BAR ANTENNA LI, F2 FERRITE BAR ANTENNA LI, F3 FERRITE BAR ANTENNA LI.

DIODES:
D1 (DET-AVC), D2 (AFC).

TRANSISTORS:
Q1 2SA102AA, Q2 2SA101A, Q3 2SA101BAorBB, Q4 0A-90, Q5 2SB175A, Q6 2SB175A, Q7 2SB175A, Q8 2SB172A, Q9 2SB172A.


DIODES:



Admiral


Chassis 8B4, Models YH312, YH313

PRECISION WIRED SYSTEM 2014B377-15




Admiral

Chassis 10A2, Model YH321



COMPONENT & ALIGNMENT LOCATIONS, TOP VIEW



COMPONENT CONNECTIONS TO BACK OF BOARD & WIRING





Diagram of 12B2 Tuner across pages 18-19. See page 20 for 4F4 pre-amp and 8L3 power unit diagrams. List of models in chart at right.



MODEL CHART			
MODEL	NAME	FINISH	CHASSIS
YG8201	Brookshire	Walnut	12B2, 4F4, 8L3
YG8215	Dunhill	Maple	RC7K4K-93AZ
YG8229	Marseilles	Cherrywood	

YG411 IDENTIFICATION CHART			
MODEL	TYPE	FINISH	CHASSIS
TM441	Tuner	Walnut	12B2
PA451	Pre-amplifier	Walnut	4F4A
PS461	Power Unit	Walnut	8L3A
SS1501A	Speaker	Walnut	2 enclosures
RP471	Record Changer	Walnut	RC7K4K-93AZ
YG411	Complete Unit	Walnut	All above




SCHEMATIC FOR 12B2 AM-FM-MX TUNER CHASSIS

ADMIRAL Chassis 12B2 Tuner Schematic Diagram (Continued)




AM IF 455 KC.
FM IF 10.7 MC.


PRECISION WIRED SYSTEM 714E365-1



ADMIRAL 4F4, A, Pre-Amp, and 8L3, A, Power Unit, Continued



SCHEMATIC FOR 4F4, 4F4A PRE-AMP CHASSIS



Emerson Radio

MODELS:

31T09, 31T10, 31T11
31L09, 31L10, 31L11

Chassis 120791, 120792, 120793, 120794. Similar Chassis 120826, 120828, are also used in some of these models.





31L11


SERVICING PRECAUTIONS

- 1) Do not operate the chassis without a loudspeaker or suitable dummy load connected to the secondary of the audio output transformer, since this may result in damage to the audio output transistors.
- 2) Note that B - (chassis ground) is connected to one side of the power line through R-11. For this reason, an isolation transformer must be used whenever servicing procedures require that a signal be conductively (by direct connection) injected into the receiver, otherwise damage to the chassis may result.

CH.120791,792,793,794





EMERSON Chassis 120789, Models 31L07, 31L08
(See adjacent page at right for schematic diagram)



REPLACEMENT INFORMATION FM TUNING UNIT 471538

When removing the FM tuning unit for exchange or replacement, be sure to retain the dial string pulley, associated mounting parts and rubber grommets. New units are supplied by the factory complete with metal cover and vacuum tube, but less the items noted above.

DIAL STRINGING






CHASSIS No. 120789

EMERSON Chassis 120789, Models 31L07, 31L08, Continued


Emerson Radio

MODELS: 31T12, 31T13,
31L12, 31L13, 31L14
CHASSIS: 120818, 120819




(For schematic diagram see page at right)

ALIGNMENT POINTS




ETCHED CIRCUIT BOARD - MAIN CHASSIS SECTION (BOTTOM VIEW)

DIAL-CORD STRINGING VIEWED FROM FRONT




NOTE: WHEN REMOVING OR REPLACING CHASSIS, IT IS RECOMMENDED THAT LEAD DRESSING AND CAPTIVATION BE MAINTAINED.

DIAL STRINGING



ETCHED CIRCUIT BOARD - TUNING SECTION (BOTTOM VIEW)

EMERSON Chassis 120818, 120819, Models 31L12, 31L13, 31L14, 31T12, and 31T13, continued from page at left



SERVICING OF ETCHED CIRCUIT BOARDS

When servicing etched circuit boards, it is recommended that a low-wattage soldering iron (approximately 20 to 30 watts) be utilized. Under no circumstances should an excessive amount of heat be applied to the etched foil, since this will result in the etched wiring becoming unbonded from the circuit board. Broken foil leads, if encountered, may be repaired by soldering a piece of stiff hook-up wire across the break. When soldering, a small stiff-bristled brush should be used to wipe away melted solder before it has a chance to accumulate or drip into adjacent wiring or components.


CONDITIONS FOR MEASUREMENT OF VOLTAGE READINGS INDICATED ON SCHEMATIC DIAGRAM

- 1) Voltage measurements are positive DC, taken between points indicated and common terminal of electrolytic capacitor C-66.
- 2) Volume control set for minimum volume and tuning capacitor fully open with no signal applied.
- 3) Measurements taken with SW-2 in following positions: Q-1, 2, 3, 7 (FM) Q-4 (AM) Q-5, 6, 8, 9, 10, 11 (AM or FM)

Emerson Radio

MODEL-CHASSIS


31L15 120797
31L17 120798
31T15 120795
31T17 120796



CH.120795,796,797,798

ALIGNMENT INSTRUCTIONS


STEP	SIGNAL GENERATOR		RADIO DIAL SETTING	OUTPUT METER	ADJUST.
	COUPLING	FREQUENCY			
1	Form loop of several turns and radiate signal into receiver.	455 KC	Variable condenser fully open.	Across voice coil.	T-3 T-2 T-1
2	As above	600 KC	600 KC	As above	L-2
3	As above	1638 KC	Variable condenser fully open.	As above	Trimmer CT-B (Osc.)
4	As above	1420 KC	Tune for maximum output.	As above	Trimmer CT-A (Ant.)



ETCHED CIRCUIT BOARD (BOTTOM VIEW)


32P06, 32P07
CH. 120815
32P06A, 32P07A
CH. 120832

Emerson Radio




TRANSISTOR REPLACEMENT INFORMATION

CHASSIS PRODUCTION	RESISTANCE VALUES EMPLOYED			USE ONLY THE FOLLOWING REPLACEMENTS	
	R-4,5	R-8,9	R-15,16	Q-1,2	Q-3,4
GROUP A	330 K	68 K	12 K	815181-B	815180-3 OR -4
GROUP B	220 K	82 K	8.2 K	815181-D	815180-7




TERMINAL IDENTIFICATION -
Q-3, Q-4


MODEL : 32P01A
MODEL : 32P12
CHASSIS: 120833




EMERSON Chassis 120836, Models 32P09, 32P10, 32P11



ETCHED CIRCUIT BOARD
(Top View)




ETCHED CIRCUIT BOARD
(Bottom View)



GENERAL ELECTRIC


Model P891A



CHASSIS REMOVAL

1. Remove tuning, volume and tone knobs.
2. Remove two Phillips-head screws located on cabinet back.
3. Remove six 1/4" hex-head screws from circuit board.


TRANSISTOR MTG PATT




NOTES

1. UNLESS OTHERWISE NOTED CAPACITORS MORE THAN 1 = MMF CAPACITORS LESS THAN 1 = MF RESISTORS ARE 1/2 WATT K = 1000
2. VOLTAGES ARE NEGATIVE WITH RESPECT TO GROUND UNDER NO SIGNAL CONDITIONS AND VOLUME CONTROL MINIMUM.


PIN CONNECTIONS FOR IF MODULE




PIN CONNECTIONS FOR AUDIO MODULE



BOTTOM VIEWS






MODEL P780H WIRING DIAGRAM - BOTTOM VIEW

GENERAL ELECTRIC

Models P740A, P741A, P915E, P916E, P917E, P9151E, P9161E, P9171E




NOTES: 1. UNLESS OTHERWISE SPECIFIED, TRANSISTOR PARTS ARE 100% TESTED AND APPROVED.

TRANSISTOR NO.	EMITTER	BASE	COLLECTOR
TR1	1	2	3
TR2	1	2	3
TR3	1	2	3
TR4	1	2	3
TR5	1	2	3
TR6	1	2	3
TR7	1	2	3
TR8	1	2	3

- UNLESS OTHERWISE SPECIFIED, TRANSISTOR PARTS ARE 100% TESTED AND APPROVED.
- VOLTAGES ARE NEGATIVE WITH RESPECT TO GROUND.
- COMPONENT VALUES ARE CHANGED DURING PRODUCTION BECAUSE OF TRANSISTOR CHANGES.
- ALL VOLTAGE READINGS TAKEN WITH SIGNAL CONDITION.

BOTTOM VIEW OF COMPONENTS




NOTES:

When TR2 is RS-5208 and TR3 is RS-5314, R4 becomes 47K, R8 becomes 15K.

When TR2 is RS-3862 and TR3 is RS-3863, R4 becomes 33K, R8 becomes 12K.

When TR6 is RS-3904, R24 is 180 Ohms.



When TR6 is RS-3948 or RS-3949, R24 is 270 Ohms.



COMPONENT WIRING DIAGRAM (BOTTOM VIEW) FOR RADIO MODELS P915E AND P916E

GENERAL ELECTRIC

Model P955E



STRINGING DIAGRAM

- ALIGNMENT**
1. SET VOLUME CONTROL FOR MAXIMUM SIGNAL WITH TONE SIGNAL.
 2. GENERATOR TO RECEIVER.

TABLE OF VOLTAGES



OH-1	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5
4.7	0	.2			
IM-1	.1	0	.2	4.7	
	PIN 1	PIN 2	PIN 3	PIN 4	
	0	.18	4.6	0	
AM-11	PIN 5	PIN 6	PIN 7	PIN 8	
	.185	.3	3.1		
	PIN 9	PIN 10	PIN 11	PIN 12	
	3.1	3.1	6	4.7	
	PIN 13	PIN 14			
	0	.07			

TROUBLESHOOTING

IMPORTANT: The audio output terminals of the radio must be D.C. isolated from ground during servicing procedures. This is to prevent the audio output transistors from becoming damaged by excess voltages in the audio circuit. Therefore, care must be exercised in using test equipment that may cause a D.C. path to ground.

Use of a VOM creates no particular problem as the meter is isolated from ground. If a VTVM is used, a 100 MFD., 200 volt electrolytic capacitor must be inserted in the negative probe to isolate the VTVM.

1. REPAIR OR REPLACE WITH NEGATIVE WITH SIGNAL CONDITIONS AND VOLUME.
2. CAPACITORS MORE THAN 1 - MFD. UNLESS OTHERWISE NOTED.
3. RESISTORS ARE 1/2 WATT, 1% TOLERANCE, UNLESS OTHERWISE NOTED. SHOWN ARE A POSSIBLE COMBINATION OF RESISTORS. THESE COMPONENTS ARE FREQUENTLY CHANGED.



PIN CONNECTIONS FOR CONVERTER MODULE (VIEWED FROM COMPONENT SIDE)


CHASSIS REMOVAL

1. Remove volume and tuning knobs.
2. Remove two Phillips-head screws from cabinet back.
3. Remove seven hex-head screws from circuit board.
4. Remove one hex-head screw inside battery compartment.
5. Label and unsolder wires going to speaker and battery terminals.
6. Carefully lift circuit board from cabinet.



GENERAL ELECTRIC

Models P1700A, P1701A, P1704A



COMPONENT SUBSTITUTION CHART

GROUP	1	2	3	4	5	6	7	8	9	10	11	12	13	14
TR5	RS-5551	RS-5551	RS-5551	RS-5552	RS-5552	RS-5552	RS-5552	RS-5553	RS-5553	RS-5553	RS-5553	RS-5553	RS-5554	RS-5554
TR7,8	RS-5757	RS-5758	RS-5759	RS-5756	RS-5757	RS-5758	RS-5759	RS-5755	RS-5756	RS-5757	RS-5758	RS-5759	RS-5755	RS-5756
R15	150K	150K	150K	180K	180K	180K	180K	220K	220K	220K	220K	220K	270K	270K
R23	39	47	50	22	39	47	56	22	22	39	47	56	22	22
GROUP CONT'D.	15	16	17	18	19	20	21	22	23	24	25	26	27	
TR5	RS-5554	RS-5554	RS-5554	RS-5555	RS-5555	RS-5555	RS-5555	RS-5556	RS-5556	RS-5556	RS-5557	RS-5557	RS-5557	
TR7,8	RS-5757	RS-5758	RS-5759	RS-5755	RS-5756	RS-5757	RS-5758	RS-5754	RS-5755	RS-5756	RS-5754	RS-5755	RS-5756	
R15	270K	270K	270K	330K	330K	330K	330K	330K	330K	330K	390K	390K	390K	
R23	39	47	56	22	22	39	47	22	22	22	22	22	22	

IF 455 KC. NOTES

- UNLESS OTHERWISE NOTED, CAPACITOR VALUES MORE THAN 1-MF CAPACITOR VALUES LESS THAN 1-MF RESISTOR ARE 1/2 WATT, 5% TOLERANCE.
- VOLTAGES ARE NEGATIVE WITH RESPECT TO GROUND UNDER NORMAL CONDITIONS AND VOLUME CONTROL AT MINIMUM.
- REPLACE TRANSISTOR WITH TYPES SHOWN BY CATALOG NUMBER LISTED IN PART LIST.
- SEE COMPONENT SUBSTITUTION CHART FOR VALUE.





TABLE OF TRANSISTOR VOLTAGES			
	EMITTER	BASE	COLLECTOR
TR1	-3.5	.5	2.5
TR2	-1.5	.4	2.5
TR3	-1.5	.4	2.5
TR4	-3.4	.4	2.4
TR5	0	1.3	2.3
TR6	.2	.2	0
TR7	-.04	1.9	2.7
TR8	-.04	1.9	2.7
TR9	1.5	1.5	0
TR10	0	0	0


SUPPLY VOLTAGE	
B1	3V
B2	2.45V
B3	2.45V



GENERAL ELECTRIC


TU50 FM-AM Tuner (Diagram and data on next two pages)

(TU500 series type tuner is practically to TU50, but has mechanical housing and flywheel tuning.)




TU50 DIAL CORD RESTRINGING

1. Place gang to open position.
2. Hook on end of spring on gang drum and bring dial cord around drum and under tuner chassis.
3. Remove the two screws nearest the audio amplifier that hold the tuner to the flat plate. Loosen the other two tuner screws.
4. Tilt the tuner up to a vertical position. (See sketch.)
5. Follow the diagram for restringing the dial cord.



TU50 TUNER COMPONENT LAYOUT BOTTOM VIEW

GENERAL ELECTRIC TU50 Tuner Schematic Diagram (Continued)



TU50 SWITCHING

POS.	S2A	S2B
1	ON	OFF
2	ON	OFF
3	OFF	ON
4	OFF	ON
5	OFF	ON

All voltages are negative with respect to ground (chassis), with no signal applied, except for measurements in stereo circuits.
Zener diode (D5) voltage is -12 volts, $\pm 5\%$. Chart is made for 12.0V Zener diode.
Other voltages have a tolerance of $\pm 15\%$.



TERM. VIEW OF Q2, Q3, Q5, Q6, & Q8




TERM. VIEW OF Q1



TERM. VIEW OF Q4, Q9, Q10, Q12, Q13, Q14, & Q15





TERM. VIEW OF Q7




VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

GENERAL ELECTRIC

TU50 Tuner (Continued)



- NOTES:
1. Capacitor values more than 1 in mfd; capacitor values less than 1 in mfd, unless otherwise noted.
 2. All resistors in ohms, 1/2 watt, 10% tolerance, unless otherwise noted.
 3. AM sensitivity is given as the input required to give 30mV audio output. Input = 45KΩ/100KΩ, 30% modulation, 500 input impedance.
 4. FM sensitivity is given as the input required to give an audio output that is 3dB below maximum output. Input = 10.7mc/98mc, 22.5K deviation, 500 input impedance, except 300Ω at antenna terminals.



GENERAL ELECTRIC T2AB TRANSISTOR AMPLIFIER



TERMINAL VIEW OF
Q1, Q2, Q5 Q3, Q4
Q6 Q7, Q8

Unless Otherwise Noted:
All voltages shown are typical voltages with no signal applied to circuit.
Measurements shown may deviate $\pm 10\%$.
A - denotes amp connectors
Resistors shown are 1/2 watt. K = 1000 meg = 1,000,000
Capacitor values less than 1 in mfd; capacitor values more than 1 in mfd
Arrows on controls indicate clockwise rotation.
DC voltages measured from B-(ind) with 20,000 ohm-per-volt meter.
Line voltage maintained at 120 volts AC, 60 cycles.
BOWTIES INDICATE CUT POINTS ON CONDUCTOR PATTERN
FOR CIRCUIT TESTING WITH OHMMETER.

Magnavox


R252 SERIES RADIO

(VIEWED FROM COPPER SIDE)




- NOTES: UNLESS OTHERWISE SPECIFIED
1. ALL RESISTORS ARE 1/2W, 10%.
 2. CAPACITANCE VALUES OF 1 AND LESS ARE IN MICROFARADS.
 3. CAPACITANCE VALUES GREATER THAN 1 ARE IN MICROFARADS.
 4. EP = EARLY PRODUCTION
 5. DC VOLTAGES ARE MEASURED WITH A HIGH IMPEDANCE VTVM, NO RF INPUT, AND A LINE VOLTAGE OF 120VAC.

IF 455 KC.




Magnavox

AM-802 PORTABLE TRANSISTOR RADIO



Magnavox A505 SERIES AMPLIFIER CHASSIS




117 VAC
MODEL
A505-01, 04,
09, & 11

117 VAC
MODEL
A505-02, 03,
05, 06, 07 & 10

ALTERNATE CONNECTOR

NOTES:
1 VOLTAGES MEASURED WITH VTVM,
NO INPUT SIGNAL.
2 SOME EARLY CHASSIS HAD
100K RESISTORS AT R18 & R20.



MODEL	C12	C13	R18	R20	C15	C16	PC5
A505-11	250 MF, 10V	250 MF, 10V	100K	100K	1000	1000	100K
A505-10	250 MF, 10V	250 MF, 10V	68K	68K	OMIT	OMIT	100K
A505-09	250 MF, 10V	250 MF, 10V	68K	68K	OMIT	OMIT	100K
A505-07	250 MF, 10V	250 MF, 10V	68K	68K	OMIT	OMIT	100K
A505-06	100 MF, 10V	100 MF, 10V	68K	68K	OMIT	OMIT	100K
A505-01	100 MF, 10V	100 MF, 10V	68K	68K	OMIT	OMIT	100K






MATSUSHITA ELECTRIC CORPORATION OF AMERICA

MODEL RE-124



Top View - Parts Identification, Alignment Points.

MONTGOMERY WARD & CO.
Airline Model GEN-1336A




MONTGOMERY WARD & CO.

Models GEN-1808A, GEN-1837A,
GEN-1847A, GEN-1857A,
GEN-1877A, GEN-1897A.

NOTES:

1. ALL CAPACITANCE VALUES ARE IN MICROFARADS + 80% - 20% 50V MIN. UNLESS OTHERWISE INDICATED.
2. ALL RESISTANCE VALUES ARE IN OHMS, 1/2W ± 10% UNLESS OTHERWISE INDICATED.
3. VOLTAGES SHOWN AT EACH TRANSISTOR ELECTRODE (± 20%) MEASURED TO COMMON GROUND WITH A VTVM WITH NO INPUT SIGNAL AND VOLUME CONTROL SET AT MAXIMUM, NEGATIVE GROUNDING.
4. ALL COIL AND TRANSFORMER RESISTANCES ARE MEASURED OUT OF CIRCUIT. RESISTANCES LESS THAN 1 OHM ARE NOT SHOWN.
5. * LIGHTED DIAL ON SOME MODELS ONLY

SWITCH ON CLOCK
MODELS LOCATED ON
TIMER MECHANISM




MOTOROLA

**MODEL AC40A
CHASSIS HS-4152**


**MODEL AC5B
CHASSIS HS-4152**

PLATED BOARD WIRING LEGEND
 = B+ = AVC = FIL = B-




MOTOROLA

**MODEL AT23A
CHASSIS HS-4143**



MOTOROLA

MODEL X60 CHASSIS HS-6127



MOTOROLA**MODEL X65****CHASSIS HS-6133**


(Diagram and other service data on the next page adjacent at right)

ALIGNMENT

Connect an output meter across the speaker. Set volume to maximum. Attenuate signal generator output so as not to exceed 50 milliwatts (.64V) on output meter at all times to prevent overloading and AGC action. Alignment should be performed with the chassis installed.

STEP	GENERATOR CONNECTION	GENERATOR FREQUENCY (1000 cycle mod)	GANG SETTING	ADJUST	REMARKS
IF ALIGNMENT					
1.	Radiation loop*	455Kc	Fully opened (1620Kc)	1, 2, 3 & 4	Adjust for maximum.
RF ALIGNMENT					
2.	Radiation loop*	1620Kc	Fully opened (1620Kc)	5	Adjust for maximum.
3.	"	1400Kc	Tune for maximum at 1400Kc	6	Adjust for maximum.
4.	"	1400Kc	Tune for maximum at 1400Kc	7	Adjust for maximum.

*Connect generator output across 5" diameter, 5-turn loop and couple inductively to receiver antenna. Keep radiation loop at least 15" from receiver antenna.

**BOTTOM VIEW**

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA
**MODEL X65
CHASSIS HS-6133**

(See preceding page at left
for additional service data)

The external power supply jack, when used in conjunction with the optional accessory power supply adaptor, Model HK-73), allows the radio to be operated from a 120 volt, 60 cycle, AC power supply. When the HK-73 is plugged into the radio, the batteries are automatically disconnected from the radio.


*PUSHBUTTON SWITCH (BATTERY LIFE INDICATOR)
IS LOCATED ON FRONT OF RADIO-PUSH TO CLOSE

NOTES:
CAPACITORS-UNLESS OTHERWISE SPECIFIED,
DECIMAL VALUES IN MF; ALL OTHERS IN MMF.
VOLTAGES-MEASURED FROM POINT INDICATED
TO GROUND WITH A VTVM $\pm 10\%$ NO SIGNAL
IN VOL AT MIN.

ZERO SIGNAL CURRENT-MAX 12MA (MIN VOL)
TUNING RANGE-532 KC TO 1620 KC, IF-455 KC


LINE UP SLIDER WITH EDGE OF DIAL
BACKGROUND & CEMENT STRING TO SLIDER


DIAL STRINGING DETAIL



MOTOROLA

MODEL X62 CHASSIS HS-6131




MOTOROLA**MODEL X58****CHASSIS HS-6136**

MOTOROLA

MODEL X61

CHASSIS HS-6137

(Other service material on the next page adjacent at right)




CAPACITORS-UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF; ALL OTHERS IN MMF.

VOLTAGES-MEASURED FROM POINT INDICATED TO GROUND WITH A VTVM $\pm 10\%$. NO SIGNAL IN, VOL AT MIN.

RESISTOR $\pm 20\%$ UNLESS OTHERWISE SPECIFIED.

* PUSHBUTTON SWITCH (BATTERY LIFE INDICATOR) IS LOCATED ON FRONT OF RADIO - PUSH TO CLOSE ZERO SIGNAL CURRENT - MAX 14 MA @ 1N VOL




PARTS LOCATION

CHASSIS SERVICE AND REMOVAL

1. From front of radio, remove two (2) control knobs and nuts that mount the earphone jack and the external power supply jack.
2. Remove the two (2) cabinet mounting screws (they are located on the sides of the cabinet, under the carrying handle - lift the handle to expose them).
3. Lift the escutcheon and chassis as an assembly out of the cabinet.
4. To remove the chassis from the escutcheon, remove the battery, remove three (3) chassis mounting screws and, if necessary, unsolder leads connected to chassis.

MOTOROLA

Model X61, Chassis HS-6137
(Continued)


ALIGNMENT


Connect an output meter across the speaker. Set volume to maximum. Attenuate signal generator output so as not to exceed .40 volt on output meter at all times to prevent overloading and AGC action. Alignment should be performed with the chassis in the cabinet.


STEP	GENERATOR CONNECTION	GENERATOR FREQUENCY (400 cycle mod)	GANG SETTING	ADJUST	REMARKS
IF ALIGNMENT					
1.	Radiation loop*	455Kc	Fully opened (1620Kc)	1, 2, 3 & 4	Adjust for maximum. Repeat adjustments #1 and #2.
RF ALIGNMENT					
NOTE: Before performing RF alignment, check oscillator tuning range; with gang fully opened, set should tune to 1620Kc $\pm$ 15Kc; with gang fully closed, 532Kc $\pm$ 5Kc. If oscillator does not cover this range, perform Steps A, B and C at this point. . . . otherwise, skip over them and go on to Step 2.					
	A. Radiation loop*	532Kc	Fully closed (532Kc)	7	Adjust for maximum.
	B. Radiation loop*	1620Kc	Fully opened (1620Kc)	5	Adjust for maximum.
	C. Repeat Steps A and B until oscillator covers required range; Step B should be last adjustment.				
2.	Radiation loop*	1620Kc	Fully opened (1620Kc)	5	Adjust for maximum.
3.	Radiation loop*	1400Kc	Tune for maximum	6	Adjust for maximum.

*Connect generator output across 5" diameter, 5-turn loop and couple inductively to receiver antenna. Keep radiation loop at least 12" from receiver antenna.



MOTOROLA
MODEL XP68B
CHASSIS HS-6202






BOTTOM VIEW

MODEL XP69B - PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM WIRING SIDE OF BOARD)



MOTOROLA Model XP69B, Chassis HS-6207


(See page adjacent at right for circuit diagram)



TOP VIEW

MODEL XP69B - PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM COMPONENT SIDE OF BOARD)






BOTTOM VIEW

MODEL XP73B - PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA Model XP73B, Chassis HS-6208
(See preceding page for circuit diagram)






TOP VIEW

MODEL XP73B - PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM COMPONENT SIDE OF BOARD)


MOTOROLA

MODELS XT2B, 3B; XC11B, 12B, 13B, 14B


CHASSIS HS-7201



NOTES
CAPACITORS-UNLESS OTHERWISE SPECIFIED,
DECIMAL VALUES IN MF. ALL OTHERS IN PF
VOLTAGES MEASURED FROM POINT INDICATED
TO GROUND WITH A VTVM. $\pm 10\%$ NO SIGNAL IN.
VOL AT MIN.
AM RANGE 535KC TO 1620KC AM IF 455KC



DIAL STRINGING DETAIL



BOTTOM VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

MODELS
TC7B, TC8B
TT14B, TT15B


CHASSIS
HS-8206
HS-8207

MOTOROLA

(For diagram see next page adjacent at right)


CHASSIS REMOVAL (All Models)

1. Remove selector and tuning knobs only. Loudness and tone control knobs are captivated.
2. Remove clock control knobs.
3. Remove clock crystal by inserting screwdriver between cabinet and bottom edge of crystal below the letters AM on dial scale. Release catch and lift out crystal.
4. Remove dial pointer by carefully pulling straight out.
5. From rear of chassis, remove three (3) screws along front chassis apron from below chassis.
6. Remove two (2) screws on vertical chassis above loudness control.
7. Unsolder speaker leads and necessary clock leads.
8. Carefully pull chassis from cabinet front.



TOP VIEW

FM-RF PLATED BOARD (PART OF
CHASSIS HS-8206 & HS-8207)




SERVICING INFORMATION

MOTOROLA

MODELS
BC9B
BT16B


MODEL
BT3A
BC6A

CHASSIS
HS-8201
HS-8202





MODEL BC6A

(AM GANG FULLY CLOSED)



DIAL STRINGING DETAIL



MOTOROLA**MODEL XP1C CHASSIS HS-66200****NOTES:**

CAPACITORS - UNLESS OTHERWISE SPECIFIED
DECIMAL VALUES IN MF. ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED
TO CHASSIS WITH A VTVM. $\pm 10\%$ NO SIGNAL INPUT.
INPUT VOLTAGE - 3V DC
TUNING RANGE - 540 TO 1610KC
IF FREQ - 455KC



Q1 THRU Q7

BOT VIEW

GERMANY

L1 CONN


TERMINAL VIEW

T4 CONN

BOT VIEW

T1, T2, T3 & L2 CONN

BOT VIEW

**BOTTOM VIEW**

SC-2700

MODEL XP1C - PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION



VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA

(Diagram and other data on page at right)

MODEL XP3C

CHASSIS HS-66202



MODEL XP3C PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)


BOTTOM VIEW

MODEL XP3C PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)

TOP VIEW


MOTOROLA**MODEL XP3C****CHASSIS HS-66202**

(Continued from preceding page)




NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED,
DECIMAL VALUES IN MF, ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED TO
GROUND WITH VTVM, $\pm 10\%$.


INPUT VOLTAGE - 6V DC
TUNING RANGE - 50KC TO 1610KC
IF FREQ - 455KC
ZERO SIGNAL CURRENT - APPROX 13MA.



PARTS LOCATION



BEFORE INSTALLING DIAL
SCALE, REMOVE MTG SCREW
BUT HOLD ONTO PULLEY.



BEFORE STARTING STRINGING, ROTATE GANG
SHAFT & PULLEY FULLY COUNTERCLOCKWISE;
THEY SHOULD BE IN POSITION AS SHOWN.

MODEL XP3C DIAL STRINGING DETAIL

MOTOROLA


Model XP7C, Chassis HS-66206



CHASSIS REMOVAL

1. From front of radio, remove two (2) control knobs and dial scale.
2. From rear of radio, open back panel by unsnapping the three (3) tabs at top of panel.
3. Remove two (2) screws holding ferrite antenna from sides of radio.
4. Remove six (6) chassis mounting screws. If necessary, unsolder leads connected to chassis before

removing chassis from cabinet.
5. If it becomes necessary to re-move the earphone jack or power jack, use tool, Motorola Part No. 66A646211.



TOP VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM COMPONENT SIDE OF BOARD)

BOTTOM VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION
(VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA Model XP7C, Chassis HS-66206 (Continued)


RADIO SERVICING INFORMATION

MOTOROLA


MODEL XP7C CHASSIS HS-66206

(For service data on plated chassis and parts locations see preceding page at left)

NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED
DECIMAL VALUES IN MF. ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED
TO CHASSIS WITH A VTVM. $\pm 10\%$ NO SIGNAL INPUT.
INPUT VOLTAGE - 6V DC
TUNING RANGE - 540 TO 1610 KC
IF FREQ - 455KC





PARTS
LOCATION




MOTOROLA

MODEL XP2C CHASSIS HS-66201



NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED
DECIMAL VALUES IN MF. ALL OTHERS IN PF.


INPUT VOLTAGE - 3V DC
TUNING RANGE - 540 TO 1610KC
IF FREQ - 455KC



MOTOROLA

MODELS AC4B, AC43B, AT30B, AT31B

CHASSIS HS-67201 & HS-68202



MODEL AC43B



MODEL AT31B

NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF, ALL OTHERS IN PF.
RESISTORS - 1/2 WATT FIXED COMPOSITION, 20% UNLESS OTHERWISE SPECIFIED.
VOLTAGES - MEASURED FROM POINT INDICATED TO CHASSIS WITH A VTVM. $\pm 10\%$ NO SIGNAL INPUT
TUNING RANGE - 535KC TO 1620KC (IF-455KC)


BOARD WIRING LEGEND

$\square$ = B+ $\square$ = AVC $\square$ = FIL $\square$ = B-



CHASSIS REMOVAL

1. Remove cabinet back - 4 screws hold it in place.
2. Remove chassis mounting screw at base of chassis and screw at tuning gang mounting bracket.
3. Pull off volume knob ONLY. (Do not pull captivated tuning knob.)
4. Unsolder appropriate leads to slide chassis out of tuning knob and cabinet.




* DASHED JUMPER (NOT IN CLOCK MODELS)

MOTOROLA


MODEL TM5A

(Diagram and other data on the next page at right)



TOP VIEW





PLATED CHASSIS BOARD WIRING (AS VIEWED FROM COMPONENT SIDE)



BOTTOM VIEW

PLATED CHASSIS BOARD WIRING AS VIEWED FROM BOTTOM (COMPONENTS SHOWN ARE LOCATED ON OPPOSITE SIDE)


NEEDED 1966 RADIO SERVICING INFORMATION



MOTOROLA


Models 232, 233, 235S

(Continued from preceding page)



AVC VOLTAGE CHECKS	
A CHECK FOR PROPER AVC ACTION IN THIS SET CAN BE MADE AS FOLLOWS:	
WITH NO INPUT SIGNAL (OR IN-BETWEEN STATIONS) THE DC VOLTAGE FROM THE AVC LINE (C2) ON SCHEMATIC WITH RESPECT TO GROUND SHOULD BE SLIGHTLY POSITIVE (APPROXIMATELY +.85 VOLTS).	INPUT SIGNAL STRENGTH
	NO SIGNAL (OR IN-BETWEEN STATIONS)
	APPROX 10,000 MICROVOLTS (MEDIUM POWER STATION)
WITH AN INPUT SIGNAL, THIS VOLTAGE WILL TEND TO GO NEGATIVE, ITS MAGNITUDE DEPENDING ON SIGNAL STRENGTH.	AVC VOLTAGE DEVELOPED
	APPROX +.85 VOLTS
	APPROX +.5 VOLTS
	APPROX -.5 VOLTS


SOME TYPICAL EXAMPLES ARE SHOWN AT RIGHT.



PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)

RADIO

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)





PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA

MODEL TM295M

(Service material continued on the next page, adjacent at right)





CAUTION
"A" LEAD MUST BE CONNECTED TO POSITIVE (+) SIDE OF POWER SUPPLY. RADIO WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT IF CONNECTED OTHERWISE.

NOTES:
CAPACITORS-UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF, ALL OTHERS IN MMF. VOLTAGES-MEASURED FROM POINT INDICATED TO CHASSIS WITH A VTVM $\pm 10\%$ NO SIGNAL IN.

INPUT VOLTAGE-14VDC
TUNING RANGE-540KC TO 1610KC
IF FREQ-262.5KC

NOTE:
ON L1, L2, L3 & L4 CONNECTION DETAIL, BOT REFERS TO LEAD AT BOTTOM OF COIL, I.E. NEAREST THE TERMINAL STRIP. THE SECONDARY WINDING IS THE OUTER MOST WINDING.



POWER TRANSISTOR CURRENT ADJUSTMENT - After replacing a power transistor, the collector current should be checked and adjusted for proper operation.

A. Insert a low range (0-1 or 0-2 amp) DC ammeter in the primary ground return lead of the output transformer (T-4). Connect the negative terminal of the meter to ground.

CAUTION: Be sure the speaker ground lead is connected in common with the transformer ground lead to the positive terminal (see SCHEMATIC DIAGRAM).

B. Turn the radio on and allow it to heat up for about 15 minutes.

C. Adjust the bias control (R-20) for a reading of 320 ma with 12.6 volts input to the radio "A" lead.

NOTE: Two values of radio input voltage are given as a convenience to service personnel in order to accommodate different power sources. The current value stated on the schematic diagram is for 14 volts input to the radio "A" lead.


AVC VOLTAGE CHECKS

A CHECK FOR PROPER AVC ACTION IN THIS SET CAN BE MADE AS FOLLOWS:
WITH NO INPUT SIGNAL (FOR IN-BETWEEN STATIONS) THE DC VOLTAGE FROM THE AVC LINE (⑤ ON SCHEMATIC) WITH RESPECT TO B+ (④ ON SCHEMATIC) SHOULD BE NEGATIVE (APPROXIMATELY -6 VOLTS.)
WITH AN INPUT SIGNAL, THIS VOLTAGE WILL TEND TO GO POSITIVE, ITS MAGNITUDE DEPENDING ON SIGNAL STRENGTH.

MOTOROLA

MODEL TM296M

(Continued from preceding page)





CAUTION
RADIO POWER LEAD MUST BE CONNECTED TO POSITIVE (+) SIDE OF POWER SUPPLY. RADIO WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT IF CONNECTED OTHERWISE.

NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF; ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED TO CHASSIS WITH A VTVM, +10% NO SIGNAL IN.
INPUT VOLTAGE - 14V DC
TUNING RANGE - 540KC TO 1610KC
IF FREQ - 262.5KC

NOTE:
ON L1, L2 & L3 CONNECTION DETAIL, BOT REFERS TO LEAD AT BOTTOM OF COIL, I.E., NEAREST THE TERMINAL STRIP. THE SECONDARY WINDING IS THE OUTERMOST WINDING.

*THESE ADJUSTMENT POINTS ARE ACCESSIBLE FROM FRONT OF RADIO




PARTS LOCATION


MOTOROLA

MODEL TM316M


(Continued on the next page adjacent at right)



DIAL STRINGING DETAIL




IF ALIGNMENT DETAIL



TOP VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)



BOTTOM VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

TOP BOT TOP BOT

1 2 3 4

2.2.5 KC.

10.2.0 KC.

16.10 KC.

ANT RECEPT

ALIGNMENT LOCATION DETAIL

* THESE ADJUSTMENT POINTS ARE ALSO ACCESSIBLE FROM FRONT OF RADIO

SPECIFIED, IN PF. INDICATED SIGNAL IN.

RADIO POWER LEAD MUST BE CONNECTED TO POSITIVE (+) SIDE OF POWER SUPPLY. RADIO WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT IF CONNECTED OTHERWISE.



NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED,
DECIMAL VALUES IN MF; ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED
TO CHASSIS WITH A VTVM, $\pm 10\%$ NO SIGNAL IN.

INPUT VOLTAGE - 14V DC

TUNING RANGE - 540KC TO 1610KC

IF FREQ. - 262.5KC




PARTS LOCATION



Q3	Q6	Q2	Q1
829C	SP1556-2	829B	829A
IF AMP	PWR AMP	CONV	RF AMP


MOTOROLA MODEL TM325M

(Diagram and other data on next page adjacent at right)



MOTOROLA**MODEL TM325M**

(Continued from preceding page)




POWER TRANSISTOR CURRENT ADJUSTMENT - After replacing a power transistor, the collector current should be checked and adjusted for proper operation.

A. Insert a low range (0-1 or 0-2 amp) DC ammeter in the primary ground return lead of the output transformer. Connect the negative terminal of the meter to isolated negative line on polarity reversing socket.

B. Turn the radio on and allow it to heat up for about 15 minutes.

C. Adjust the bias control (R-21) for a reading of 320 ma with 12.6 volts input to the radio "A" lead.

NOTE: Two values of radio input voltage are given as a convenience to service personnel in order to accommodate different power sources. The current value stated on the schematic diagram is for 14 volts input to the radio "A" lead.



NOTE:
CAPACITORS - UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF; ALL OTHERS IN MMF. VOLTAGES - MEASURED FROM POINT INDICATED TO CHASSIS WITH A VTVM, $\pm 10\%$ NO SIGNAL IN.

INPUT VOLTAGE - 14VDC


TUNING RANGE - 540KC TO 1610KC

IF FREQ - 262.5KC

⊥ - INDICATES ISOLATED NEGATIVE LINE

⏏ - INDICATES OUTER HOUSING

CAUTION
BEFORE CONNECTING "A" LEAD BATTERY POLARITY SHOULD BE CHECKED AND POLARITY REVERSING PLUG SHOULD BE CHANGED CORRESPONDINGLY; OTHERWISE SET WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT.


**AVC VOLTAGE CHECKS**

A CHECK FOR PROPER AVC ACTION IN THIS SET CAN BE MADE AS FOLLOWS: WITH NO INPUT SIGNAL (OR IN-BETWEEN STATIONS) THE DC VOLTAGE FROM THE AVC LINE (⊖ ON SCHEMATIC) WITH RESPECT TO B+ (⊕ ON SCHEMATIC) SHOULD BE NEGATIVE (APPROXIMATELY -5 VOLTS). WITH AN INPUT SIGNAL THIS VOLTAGE WILL TEND TO GO POSITIVE, ITS MAGNITUDE DEPENDING ON SIGNAL STRENGTH.


MOTOROLA

MODEL TM326M


(Diagram and other data on the next page adjacent at right)



DIAL STRINGING DETAIL




IF ALIGNMENT DETAIL



TOP VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)



BOTTOM VIEW


PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

RADIO SERVICING INFORMATION



MOTOROLA

MODEL TM326M

(Continued from preceding page at left)



NOTE:
ON L2, L3, L4 & L5 CONNECTION DETAIL, BOT REFERS TO LEAD AT BOTTOM OF COIL I.E., NEAREST THE TERMINAL STRIP. THE SECONDARY WINDING IS THE OUTERMOST WINDING.




NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF; ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED TO $\pm$ WITH A VTVM $\pm 10\%$ NO SIGNAL IN
INPUT VOLTAGE - 14V DC
TUNING RANGE - 540KC TO 1610KC
IF FREQ. - 262.5KC
 $\equiv$ INDICATES ISOLATED NEGATIVE LINE
 $\equiv$ INDICATES OUTER HOUSING

MOTOROLA


MODEL TM336M

(Diagram and other data on the next page adjacent at right)




ALIGNMENT LOCATION DETAIL

* THESE ADJUSTMENT POINTS ARE ALSO ACCESSIBLE FROM FRONT OF RADIO



TOP VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)




BOTTOM VIEW

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA

MODEL TM336M

(Continued from preceding page)



CAUTION
RADIO POWER LEAD MUST BE CONNECTED TO NEGATIVE (-) SIDE OF POWER SUPPLY. RADIO WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT IF CONNECTED OTHERWISE.

NOTES:



CAPACITORS - UNLESS OTHERWISE SPECIFIED
DECIMAL VALUES IN MF; ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED
TO WITH A VTVM $\pm 10\%$ NO SIGNAL IN

INPUT VOLTAGE - 14V DC
TUNING RANGE - 540KC TO 1610KC
IF FREQ. - 262.5KC

INDICATES ISOLATED NEGATIVE LINE


INDICATES OUTER HOUSING

FRONT OF RADIO



DIAL STRINGING DETAIL

PARTS LOCATION




MOTOROLA**MODEL TM526A**

(Diagram and other service data on the next page adjacent at right)


GENERAL INFORMATION

Universal automotive type all-transistor superheterodyne AM radio for standard broadcast reception; operates from 12 volt negative or positive ground system (by simply re-positioning a polarity reversing plug on the radio). This receiver contains a plated chassis board, 6 transistors and 2 diodes and uses an 8 ohm speaker system.

This radio is of the compact, under-dash type. In-dash installations, however, can be made in many cars with the use of trimplate kits AK-223 or KM35T. Special knobs are designed to give all installations a custom look. The tone knob and the dummy knob are reversible. For in-dash installations, the knob is used "backwards" and provides a flush fit. For under-dash installations, the knob is used "face-up" and fills the extra space where the dash would be.

**TOP VIEW**

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM COMPONENT SIDE OF BOARD)


**BOTTOM VIEW**

PLATED CHASSIS REFERENCE POINTS AND PARTS LOCATION (VIEW FROM WIRING SIDE OF BOARD)

MOTOROLA

MODEL TM526A


(Continued from preceding page)



NOTES:
CAPACITORS - UNLESS OTHERWISE SPECIFIED, DECIMAL VALUES IN MF. ALL OTHERS IN PF.
VOLTAGES - MEASURED FROM POINT INDICATED TO GND WITH A VTVM $\pm 10\%$ NO SIGNAL IN



INPUT VOLTAGE - 14V DC
TUNING RANGE - 540KC TO 1610KC
IF FREQ. - 262.5KC
INDICATES ISOLATED CHASSIS
INDICATES OUTER HOUSING

POLARITY REVERSING PLUG POSITIONS
BACK VIEW
POS GND BATT
NEG GND BATT




CAUTION
BEFORE CONNECTING RADIO POWER LEAD, BATTERY POLARITY SHOULD BE CHECKED AND POLARITY REVERSING PLUG SHOULD BE CHANGED CORRESPONDINGLY OTHERWISE SET WILL NOT OPERATE AND DAMAGE TO COMPONENTS WILL RESULT.

NOTE
ON L2, L3, L4 & L5 CONNECTION DETAIL, 80T REFERS TO LEAD AT BOTTOM OF COIL, I.E. NEAREST THE TERMINAL STRIP. THE SECONDARY WINDING IS THE OUTERMOST WINDING.



PARTS LOCATION



ALIGNMENT LOCATION DETAIL

MOTOROLA**MODELS PP200B, 201B****CHASSIS HS-2347****CHASSIS REMOVAL**


1. From rear of cabinet, remove four (4) screws along rear of handle and four (4) screws across cabinet back.
2. Remove three (3) control knobs. Carefully pull cabinet front forward and remove three (3) screws which secure chassis to cabinet front.
3. If necessary, disconnect all cables (speakers, etc.).


TRANSISTOR
BOT VIEWQ1-Q4 CONN
BOT VIEW

Q1-Q6 CONN

RECORD CHANGER REMOVAL


1. Open changer drawer to operating position.
2. Screw changer hold down screws fully into record changer base.
3. Raise the front of the changer enough to clear drawer edge and carefully slide record changer forward until it clears changer supports.
4. Lift up changer, disconnect power plug and unsolder audio leads from terminal strip on underside of the changer.




MOTOROLA**MODEL MP100B
CHASSIS HS-2348**

**MOTOROLA MODELS PP301B, 302B; SP310B; PK400B, 401B; SK450B
THRU 453B, 500B THRU 509B; 23LK412B THRU 416B
CHASSIS HS-2334, HS-2336, HS-2339, HS-2349**

Material
on pages 90
through 94.




DIAL STRINGING DETAIL - HS-2339



TOP VIEW

MULTIPLEX PLATED BOARD (PART OF CHASSIS HS-2339)

TO PILOT
SQUELCH
RIGHT
AUDIO
LEFT
AUDIO



BOTTOM VIEW


MULTIPLEX PLATED BOARD (PART OF CHASSIS HS-2339)

MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

MOTOROLA Chassis HS-2339

(Continued)



T5 RATIO DET



SCHEMATIC DIAGRAM - HS-2339



(See also pages 90 and 92)

MOTOROLA Chassis HS-2339 Service Information, Continued




MOTOROLA Chassis HS-2334

(Continued)



NOTE: DC VOLTAGES - MEASURED FROM POINT INDICATED TO 1 - WITH A VTVM + 10K WITH NO SIGNAL INPUT.
 * ONLY ON MODELS WITH FM/AM TUNER
 ① PLUGS INTO TUNER CHASSIS ON FM/AM TUNER MODELS.
 ② WHEN C-21 IS USED, C-20A IS 1000PF.
 ON CHASSIS WITHOUT C-21, C-20A IS 1000PF.
 CAPACITORS UNLESS OTHERWISE SPECIFIED
 DECIMAL VALUES IN MF, ALL OTHERS IN MMF.




SCHEMATIC DIAGRAM - HS-2334

MOTOROLA HS-2336

(Continued)

SCHEMATIC DIAGRAM - HS-2336




NOTE: DC VOLTAGES - MEASURED FROM POINT INDICATED TO B - WITH A VTVM + 10% WITH NO INPUT.
CAPACITORS - IN MF UNLESS OTHERWISE SPECIFIED.

*** ONLY ON MODELS WITH FM/AM TUNER**


1 PLUGS INTO CONNECTORS ON

2 PLUGS INTO POWER WIRING HARNESS




PHILCO

TRANSISTOR PORTABLE MODEL NT809




VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

PHILCO Models P720, P721, P722, P723, P724, P880, P881, P882, P883, P884, P885




PHILCO Models P710, P933, P941



AM IF 455 KC.
FM IF 10.7 MC.

PHILCO Schematic Diagram, Model P710, P933, P941

PHILCO Model NT814



TRANSISTOR VOLTAGE CHART								
0	0	-11	-5	0	-6	0	0	AM
-20	-10	-3	-5	0	-4	0	0	FM
0	0	-2	-7	-9	-17	-2	-2	AM
-24	-12	-15	-7	-8	-15	-2	-2	FM
0	-82	-82	-82	-82	-77	-90	-90	AM
-72	-72	-75	-75	-75	-70	-90	-90	FM
0	02	03	04	05	06	07	08	


(A) 10K, 12K OR 15K
 (B) 16K, 20K, 22K OR 27K
 REPLACE WITH ORIGINAL VALUE

Alignment Points


Bottom View - Perma-Circuit Panel

PHILCO Model NT815

(AM IF 455 KC.)
(FM IF 10.7 MC.)




NOTES
ALL VOLTAGES MEASURED WITH "PRECISION MODEL 88" VTVM FROM GROUND TO POINTS INDICATED WITH VOLUME AT MINIMUM AND NO SIGNAL. BATTERY SUPPLY 6 VOLTS-CURRENT 8.5 MA BAND SWITCH IN BC POSITION
ALL RESISTANCES MEASURED IN CIRCUIT.



BOTTOM VIEW - PERMA CIRCUIT PANEL TOP COMPONENT LAYOUT

PHILCO Tuner-Amplifier Chassis P10ST used in Models P1002 and P1718

(Diagram continued on page at right; other material on page following)




PHILCO Tuner-Amplifier Chassis P10ST used in Models P1002 and P1718

(Continued; see also next page,over)

CHASSIS REMOVAL - P10ST, P25ST,

1. Disconnect line cord and remove back.
2. Disconnect speaker cables, phono power cable, phono input cable and bin light when used.

3. Remove holddown screws at rear of chassis.
4. Remove screws inside of cabinet at corners of front bezel.
5. Remove screws holding EXT. SPKR. JACK PLATE to cabinet.
6. Remove chassis from front of cabinet; in drop-in models lift lid then lift chassis up and out of cabinet.



PHILCO Chassis P10ST, continued

ALL VOLTAGES MEASURED WITH VTVM "PRECISION" MODEL "88" WITH SELECTOR SWITCH IN FM STEREO POSITION, AFC SW. ON AND NO SIGNAL.

Q1, Q2, Q3, Q5, Q6, Q10, Q12, Q16

Q16 HR19 FILTER

Q14 HR11 R.H. OUTPUT


Q11 HR11 R.H. OUTPUT

Q7 HR11 L.H. OUTPUT


Q4 HR11 L.H. OUTPUT

TRANSISTOR BASING BOTTOM VIEW

Q4, Q7, Q8, Q9, Q13, Q11, Q14, Q15, Q17, Q18



Bottom View - Top Component Location P10ST Chassis



AM FM Alignment Points


ALIGNMENT INFORMATION
P10ST, P25ST, PD25ST, &
PD100ST CHASSIS

TYPICAL VOLTAGES				
Q	E	B	C	
1	7	1.3	2.7	
2	7	1.3	2.7	
3	2.1	2.7	26	
4	0	7	15	
5	2	7	31.5	
6	5	1.2	18	
7	15	15.8	32	
8	8	7.9	0	
9	7	8.0	0	
10	2.1	2.7	26	
11	0	7	15	
12	1.8	2	12.5	
13	8.6	8.2	0	
14	15	15.8	32	
15	8.6	8.3	0	
16	20	20.5	31.5	
17	8.2	8	0	
18	5.4	5.2	0	

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

PHILCO P25ST - CODE 124 CHASSIS ELECTRICAL PARTS

SYM-BOL	LOCATION	DESCRIPTION	SERVICE PART NO.	SYM-BOL	LOCATION	DESCRIPTION	SERVICE PART NO.
CAPACITORS				C31	D11	150 pf, driver C to B	30-1294-31
C1	G8	.1 mf, treble cont.	30-4706-13	C32	D2	1500 pf, FM mix. coup.	30-1294-30
C1A		100 pf, 67KC filter	30-1293-32	C33	D3	4700 pf, osc. base	30-1294-13
C2	G10	elec., 250 mf, 6V, driver emit.	30-2611-10	C34	D5	.0082 mf, AM osc. inj.	30-1294-32
C2A		220 pf, 67KC filter	30-1294-19	C36	D6	elec., 5 mf, 15V, AVC	30-2610-1
C3	G11	.1 mfd, bass cont.	30-4695-30	C36A	C7	.01 mf, B ⁺ bypass	30-1294-6
C4	F7	.1 mf, 1st audio	30-4695-30	C37	D7	220 pf, AVC coup.	30-1293-34
C5	F9	.1 mf, treble cont.	30-4706-13	C38		2200 pf, AM bypass	30-1294-29
C6	F10	.05 mf, treble cont.	30-1272-23	C39	C10	.03 mf, mx. input	30-1272-5
C7	G10	.05 mf, treble cont.	30-1272-23	C40	C1	100 pf, AM R-F coil	30-1293-32
C8	F8	150 pf, driver C to B	30-1294-31	C40A	D2	.01 mf, AM mix. coup.	30-1294-6
C9	F12	2 mfd, bass cont.	30-2612-2	C41	C3	trimmer 3 to 12.5 pf FM osc.	31-6520-37
C10	G13	.0047 mf, bass cont.	30-1294-28	C42	A5	tuning AM-FM	31-2795-1
C11	F13	.0047 mf, bass cont.	30-1294-28	C43	C2	3.9 pf, AM-FM R-F neut.	30-1221-14
C12	F7	.1 mf, 1st audio	30-4695-30	C44	C3	150 pf, FM I-F-AM R-F bypass	30-1293-22
C13	F9	elec., 250 mf, 6V, driver emit.	30-2611-10	C45	C3	100 pf, AM ant.	30-1293-32
C14	E5	4700 pf, mx. out.	30-1294-28	C46	C5	1500 pf, 1st AM I-F	30-4707-7
C15	E5	4700 pf, mx. out.	30-1294-28	C47	C7	820 pf, 1st AM I-F	30-4707-6
C16	E2	.1 mf, AM ant.	30-4706-13	C48	C7	.01 mf, B ⁺ bypass	30-1294-6
C17	E3	10 pf, FM osc. inj.	30-1221-23	C49	C8	.02 mf, AVC	30-1294-27
C17A	E3	100 pf, AM osc.	30-1293-32	C50	C10	.01 mf, AFC bypass	30-1294-6
C18	E3	4700 pf, AM osc. FB	30-1294-28	C51	B2	.01 mf, AM-FM R-F	30-1294-6
C19	E9	1800 pf, 19KC transf.	30-4707-15	C52	B3	4.7 pf, AM ant. coup.	30-1221-13
C21	E2	.01 mf, FM mix.	30-1294-6	C53	B3	7.5 pf, FM ant. pad.	30-1293-31
C21A	D2	.01 mf, B ⁺ bypass	30-1294-6	C54	B3	trimmer, 1 to 5 pf, FM ant.	31-6520-36
C22	D3	7.5 pf, FM osc. FB	30-1221-24	C55	B5	.02 mf, FM I-F-AM mix.	30-4706-32
C23	D4	.001 mf, FM osc. ret.	30-1294-20	C56	B7	.01 mf, 1st AM I-F	30-4706-22
C24	D4	56 pf, AFC	30-1287-5	C56A	B7	.01 mf, I-F emit.	30-1294-6
C25	D6	.001 AM out.	30-1294-20	C57	B7	.22 mf, AVC	30-4706-29
C26	D7	3900 pf, 38KC transf.	30-4707-17	C58	B8	2200 pf, 2nd AM I-F	30-4707-16
C27	D8	.2 mf, mx. amp.	30-4704-3	C58A	B8	.01 mf, lim. bypass	30-1294-6
C28	D8	.1 mf, mx.	30-4706-13	C59	B10	.01 mf, B ⁺ bypass	30-1294-6
C29	D9	elec., 5 mf, 25V, 38KC emit.	30-2610-2	C60	B1	elec., 5 mf, 15V, over-load	30-2610-1
C30	D10	1800 pf, mx. amp. transf.	30-4707-15				



PHILCO

**P25ST-CODE 124 TUNER-AMPLIFIER CHASSIS - MODELS
PI710, PI719, PI722,
PI735 & PI737**


(Diagram continued on next page at right;
see also the preceding two pages)

	Q1	Q2	Q3	Q4	Q5	Q6	Q7	Q8	Q9	Q10	Q11	Q12	Q13	Q14	Q15	Q16	Q17	Q18
E	.5	.5	2.3	.1	.3	0	24.5	8.7	8.2	2.3	.1	1.5	10.3	24.5	10.8	20.5	10.3	5.6
B	1	1	2.8	.7	.9	.4	25	8.4	8.1	2.8	.7	2.1	10.6	25	10.4	21	10	5.3
C	2.8	2.8	28	24	32	20	48	.2	0	28	24	12	.3	48	0	32.5	.4	.2

* AM VOLTAGES

NOTES:

1. ALL VOLTAGES AND RESISTANCES MEASURED WITH VTVM PRECISION MODEL 88.
2. ALL RESISTANCES MEASURED IN-CIRCUIT.
3. ALL VOLTAGES ARE TYPICAL VALUES TAKEN WITH LOUDNESS FULLY CCW AND SWITCHES IN FM STEREO POSITION AND LOW LEVEL SWITCH OFF UNLESS SPECIFIED OTHERWISE WITH NO SIGNAL APPLIED.
4. VOLTAGES ON Q6 WILL VARY WITH SIGNAL.



Schematic Diagram P25ST Code 124 Chassis

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

PHILCO Chassis P25ST, Models P1710, P1719, P1722, P1735, P1737, Continued

ALL TRANSISTOR TUNER/AMPLIFIERS

RF SHIELD REMOVAL: (RF Tuning Section) Top & Bottom

NOTE: Two types of RF shields were used on these chassis.

Type 1 - Top shield with a removable cover. The mounting studs are part of the top shield with mounting nuts on bottom of PW panel.


Type 2 - Top shield without a removable cover. The mounting studs are part of the bottom shield with mounting nuts on top of PW panel.

To remove type 1 top shield:



1. Remove 3 nuts holding bottom shield.
2. Unsolder ground tab and remove bottom shield.
3. Remove top cover.

To remove type 2 top shield:

1. Remove 3 nuts holding top shield.
2. Unsolder antenna lead from Gang and lift off top shield.
3. Remove 3 additional nuts on shield studs, unsolder ground tab and lift off bottom shield.



PHILCO Model P1441



Model P1441 Bottom View - Component Layout


CHASSIS REMOVAL - MODEL P1441

1. Remove 6 panel (motorboard) screws, lift panel then disconnect 2 speaker leads and audio cables from changer.
2. Remove knobs (Tone & Loudness).
3. Remove bushing nuts from control shafts.
4. Lift panel and remove chassis.


RECORD CHANGER REMOVAL - MODEL P1441

1. Remove 6 panel screws.
2. Lift front end of panel with changer and amplifier.
3. Disconnect power and audio leads.
4. Straighten changer mounting bolt clips then lift off record changer.

PHILCO Model P1442



PHILCO Model P1444




RECORD CHANGER REMOVAL - MODEL P1444

1. Lower changer drawer and remove 4 screws holding record changer to base.
2. Lift front of record changer and disconnect changer power plug, unsolder 3 leads to terminal strip.
3. Lift record changer from base.

CHASSIS REMOVAL-- MODEL P1444



1. Remove record changer (see record changer removal instructions).
2. Remove 2 knobs (Loudness).
3. Disconnect panel plug at rear of chassis panel and unsolder speaker leads from output transformer.
4. Remove 2 chassis hold down screws (one located at each end of chassis), lift chassis from base.



Model P1444 Bottom View Perma-Circuit Panel - Component Layout


PHILCO Model P1445

PHILCO Model P1445



Model P1445 Bottom View Perma-Circuit Panel - Component Layout


PHILCO Model P1446



NOTES:
1. ALL VOLTAGES MEASURED TO B-GROUND
WITH VTVM SENSOR MODEL SM112A
2. ALL COIL RESISTANCES ARE
MEASURED IN CIRCUIT

PHILCO Model P1511

Model P1511 Schematic Diagram




4. Disconnect changer power plug and two audio plugs (red & black).
5. Lift changer forward and slide rear end to the right to release mounting bolt at left rear of base plate.

CHASSIS REMOVAL - MODELS P1446 & P1511

1. Remove rear access panel (4 screws).
2. Remove cable hold down clips.
3. Remove knobs (Balance, Tone, Loudness & Treble).
4. Remove bushing nuts (3) from control shafts.
5. Lift chassis out from rear of cabinet.
6. Disconnect cables as necessary

PHILCO Models P1513, P1515




NOTES:
1. ALL VOLTAGES MEASURED TO B-GROUND WITH VTVM SENSORE MODEL 5N112A
2. ALL COIL RESISTANCES ARE MEASURED IN CIRCUIT

NOTE:
R29 SHOWN WAS ADDED IN LATER PRODUCTION R28 WAS 8.2K IN EARLY PRODUCTION

	C	B	E
PRE AMPS Q1-Q2	1.8V	.59V	.01V
DRIVERS Q3-Q4	30.8V	1.8V	1.25V
OUTPUTS Q5-Q6	57.5V	1.25V	.66V


Model P1513/P1515 Schematic Diagram




Step	Connect high side of signal gen. to—	Set signal gen. to—	Turn radio dial to—	Adjust—for peak output
1	Pin #1 of V2 (12BA6) through .01 μ f capacitor	455 kc (Modulated)	Quiet point near 1600 kc	T2 (2nd I-F trans.), top and bottom cores
2	Pin #7 of V1 (12BE6) through .01 μ f capacitor			T1 (1st I-F trans.), top and bottom cores
3	Repeat steps 1 and 2			
4	Short wire placed near antenna to radiate signal	1620 kc (Modulated)	Gang fully open	C1-B-T (osc. trimmer)
5		1400 kc (Modulated)	1400 kc signal	C1-B-T (Ant. trimmer)
6		600 kc (Modulated)	600 kc signal	T3 (osc. coil) (rock gang)
7	Repeat steps 3, 4 and 5			

RCA VICTOR

This is exact material for the following:
RGA-27 Series, Chassis RC-1213R;
RGD-30 Series, Chassis RC-1213M;
and this group of sets are very similar:
RHA-12G,N,Y, RHA-17A,E,J, RC-1213W;
RHD-13N,Y, RHD-17A,J,Y, using
Chassis RC-1213AB; RHD-21A,J,T,
using Chassis RC-1213AA.




Chassis Layout—RC-1213M, R *View from Wiring Side*



Chassis Layout—RC-1213M, R *View from Component Side*


RCA VICTOR

Models RGG-17B, RGG-22A, N, U, RGG-25B, E, G
Chassis RC-1219A, RC-1219B




ALIGNMENT PROCEDURE

Step	Connect High Side of Signal Generator to—	Signal Gen. Output	Dial Pointer Setting	Adjust for Max. Output
1				T4 (3rd I-F)
2		455 kc	Gang fully open	T3 (2nd I-F)
3				T2 (1st I-F)
4	Loop or piece of short wire placed near antenna for radiated signal	Repeat Steps 1, 2, and 3		
5		1620 kc	Gang fully open	Oscillator trimmer C1B-T
6		1400 kc	1400 kc (rock gang if necessary)	Antenna trimmer C1A-T
7		600 kc	600 kc (rock gang)	Osc. coil T1
8	Repeat Steps 5, 6, and 7			




CHASSIS REMOVAL

1. Remove tuning and volume knobs.
2. Open case.
3. Remove three screws securing chassis. (Two at battery end of board and one at speaker end.)
4. Remove nut holding earphone jack (RC-1219B) or slide earphone jack out of slot (RC-1219A).
5. Unsolder speaker wires if necessary (or remove clips holding speaker to case).
6. Unsolder battery wires if necessary.
7. Lift board out of case.




RHG 25 Series

Chassis RC-1219D




IF 455 KC.

VOLTAGES MEASURED WITH "VOLTOMETER"
FROM (+) BATTERY, SHOULD HOLD WITHIN $\pm 20\%$
WITH NEW BATTERY. VOLUME CONTROL AT
MAXIMUM & NO SIGNAL.
K=1000. ALL RESISTANCE VALUES IN OHMS.
ALL CAPACITANCE VALUES LESS THAN 1.0 ARE IN
 μF , THOSE ABOVE 1.0 ARE IN μF EXCEPT AS NOTED.
Q7 & Q8 ARE A MATCHED PAIR.



RCA Victor Model RGG-29E, Chassis RC-1221A



Step	Connect Signal Source To—	Set Signal Source To—	Set Radio Dial To—	Adjust— for maximum
1	Stator of C1A (RF Gang) through a 0.01 μ f capacitor	455 kc	Gang fully open	(3rd IF) T5
2				(2nd IF) T4
3				(1st IF) T3
4	Repeat steps 1, 2 and 3 as necessary for maximum.			
5	Standard Loop or short piece of wire placed near antenna	1620 kc	Gang fully open	(Osc. Trimmer) C1C-T
6		1400 kc	1400 kc	(RF Trimmer) C1B-T (Ant. Trimmer) C1A-T
7		600 kc	600 kc (rock gang)	(Osc. Coil) T2
8				(RF Trans.) T1
9				




- NOTES: 1. ALL RESISTANCE VALUES ARE IN OHMS UNLESS NOTED.
2. CAPACITANCE VALUES LESS THAN 1.0 ARE IN μ F.
3. VALUES 100, 1000, 10000 ARE IN P.F. (EXCEPT AS NOTED).
4. VOLTAGES MEASURED FROM POSITIVE (+) SIDE OF BATTERY (CHASSIS GROUND).

CHASSIS ACCESSIBILITY AND REMOVAL

1. Unsnap the two tabs at the bottom of the back and swing the back cover out and up.
2. Insert cells, with button end (+) to the left, into the opening in the battery compartment. Slide one cell to the left and two to the right; the fourth cell is inserted by pushing the cells on the right against the spring pressure until the fourth cell slips into place in the opening.

The chassis may be made further accessible by removing the front panel from the case; remove three (3) screws through the bottom of the case and two (2) through the top (under the handle) to permit the front panel to slide out of the case. (NOTE: The three screws through the bottom of the case also secure the battery holder.)

The chassis may be removed from the front panel by removing the five (5) screws securing it to the front panel; two at each end and one at the approximate center.




Chassis Layout—View From Wiring Side

RCA VICTOR

Chassis RC-1221B

Model RHG 30E—Black



NOTES ON ARE A MATCHED PAIR
 1. ALL RESISTANCE VALUES ARE IN OHMS, K Ω 1000
 2. CAPACITANCE VALUES LESS THAN 100 P.F. ARE IN P.F.
 3. VALUES 1.0 & ABOVE ARE IN P.F. EXCEPT AS NOTED.
 4. VOLTAGES MEASURED FROM POSITIVE (+) SIDE OF BATTERY (CHASSIS GROUND).

8 V.D.C.
 4" CELLS
 1.5" CELLS
 OR EQUIV.
 RED
 SWITCH ON
 VOL. CONTR.


BASED ON
 FOR Q1 THRU Q3

TERM. INDICATION
 FOR T1, T2, T3, T4, T5, T6, T7

TERM. INDICATION
 FOR T1, T2, T3, T4, T5, T6, T7

I.F. Alignment Information

Step	Connect Signal Source To—	Set Signal Source To—	Set Radio Dial To—	Adjust— for maximum
1	Stator of C1A (RF Gang) through a 0.01 μ F capacitor	455 kc	Gang fully open	(3rd IF) T5
2				(2nd IF) T4
3				(1st IF) T3




Chassis Layout (Wiring Side)

RCA VICTOR

RGH 12 Series

Chassis RC-1222A




BATTERY REPLACEMENT

1. Insert a coin in the slot on the top of the case and twist it to pry the front and back section apart.
2. Remove the back by swinging it open as though it were hinged at the bottom.
3. Replace the battery by snapping the connector off the old battery and onto the new one. (Note the polarized terminals.)
4. Reassemble the case by placing the bottom of the back section into the bottom of the front section and hinge the back section up into the front section and snap them together. (Small bosses on the top and bottom edges of the back section fit into small indentations inside of the edge of the front section.)

07 & 08 ARE A MATCHED PAIR
 1. ALL RESISTANCE VALUES ARE IN OHMS. R-1000
 2. CAPACITANCE VALUES LESS THAN 1.0 ARE IN P.F.
 3. VOLTAGES MEASURED WITH A "VOLTOHMIST" FROM POSITIVE (+) SIDE OF BATTERY WITH NO SIGNAL CHASSIS GROUND.

Collector	Q7 - -9.0v	Q8 - -4.5v
Base	Q7 - -4.68v	Q8 - -0.18v
Emitter	Q7 - -4.52v	Q8 - -0.02v





Wiring Side

RCA VICTOR

RHH 17 Series

Chassis RC-1222A



BATTERY REPLACEMENT


1. Insert a coin in the slot on the top of the case and twist it to pry the front and back section apart.
2. Remove the back by swinging it open as though it were hinged at the bottom.
3. Replace the battery by snapping the connector off the old battery and onto the new one. (Note the polarized terminals.)
4. Reassemble the case by placing the bottom of the back section into the bottom of the front section and hinge the back section up into the front section and snap them together. (Small bosses on the top and bottom edges of the back section fit into small indentations inside of the edge of the front section.)

IF 455 KC.

CHASSIS REMOVAL

1. Open case as described under "Battery Replacement."
2. Remove three (3) screws holding circuit board to case.
3. Unfold wires to speaker.
4. Lift up transformer side of circuit board and slide board sideways out of case. (Speaker wires are long enough to permit chassis to be laid outside of case for servicing. If necessary to separate the chassis and speaker, the speaker leads should be unsoldered from the board to avoid damaging the voice coil leads of the speaker.)

RCA Victor Models RGA-39W, RGA-40W, Chassis RC-1224



ALIGNMENT PROCEDURE

For all alignment operations connect low side of generator to chassis ground (junction of R24 and R29).

Connect output indicator across speaker voice coil.

Set volume control to maximum.

CHASSIS ACCESSIBILITY

1. Remove four Phillips head screws holding the rear cover. Remove the rear cover.
2. Remove two Phillips head screws retaining the tuning panel to the front of the cabinet.
3. Remove two Phillips head screws holding chassis retaining tabs located at rear of cabinet.
4. Slide chassis rearward to remove. If necessary, unsolder speaker leads.

To reassemble—reverse above procedure.

Oscillation on Strong Signal

In a strong signal area an oscillation may be set up which will manifest itself by clamping of the A.G.C. and by causing a reverse bias to exist between the base and emitter of Q3, the first IF transistor.


This condition may be corrected by installing a ferrite bead on the emitter lead of Q4, the second IF transistor. The installation of the bead is accomplished by unsoldering the emitter lead of Q4, slipping the lead through the hole in the bead, and reinserting and resoldering the lead in the board.

The ferrite bead is available from Parts and Accessories under stock number 116761.

Step	Connect high side signal gen. to—	Set signal gen. to—	Set radio dial to—	Adjust—for maximum output
1	Stator of C1A (RF gang) through a 0.01 mfd capacitor	455 kc (Modulated)	tuning gang fully open	T5 (3rd IF)
2				T4 (2nd IF)
3				T3 (1st IF)
4	Short wire placed near antenna to radiate signal	1620 kc (Modulated)	1620 kc (gang open)	C1B-T (Osc. trimmer)
5		1400 kc (Modulated)	1400 kc	C1A-T (RF trimmer)
6				C1C-T (Ant. trimmer)
7		600 kc (Modulated)	600 kc (rock gang)	T2 (Osc. coil)
8				T1 (RF coil)
9	Repeat above steps as necessary for best sensitivity.			

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

RCA Victor Model RGH-10



ALIGNMENT PROCEDURE

The "Souvenir" is a pocket type transistorized radio receiver designed for the reception of AM broadcasts in the range from 520 kc to 1680 kc. It is housed in a vertically styled case small enough to fit into a shirt pocket.


BATTERY REPLACEMENT

1. Grasp the front section of the case with the left hand and the back section with right hand with the thumbs near the volume control on the right side.
2. Separate the back from the front as though it were hinged at the left side.
3. Replace the battery by snapping the connector off the old battery and onto the new one.
4. Reassemble the case by placing the left side of the front and back sections together and closing them with a hinging action.

Step	Connect Signal Generator to—	Signal Gen. Output	Dial Pointer Setting	Adjust for Max. Output
1	Loop of wire placed near antenna for radiated signal	455 kc	Gong fully open	T3 (3rd I-F)
2				T2 (2nd I-F)
3				T1 (1st I-F)
4		Repeat Steps 1, 2, and 3		
5		1680 kc	Gong fully open	VC1B-T (Oscillator trimmer)
6		1400 kc	1400 kc (rock gang)	VC1A-T (Antenna trimmer)
7		600 kc	600 kc (rock gang)	L2 (Osc. Coil)
8		Repeat Steps 5, 6, and 7		

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION


RCA Victor Models RGA-12Y, RGA-15A, R, Y, RGD-20N, R, Y, Chassis RC-1213A, -K




TUBE AND CHASSIS ACCESSIBILITY

1. DO NOT ATTEMPT TO REMOVE THE KNOBS. The tuning and volume control knobs are held captive to the cabinet by retainers on their shafts.
2. Remove the back cover by lifting the protrusions on the bottom of the back cover out of the slots in the base of the cabinet.
3. Unsolder speaker leads if necessary. Avoid putting a strain on the speaker leads.
4. Remove two chassis retainers (screws or clips), one at the volume control and one of the left end mounting.
5. Grasp tuning capacitor and volume control, and pull chassis out of knobs and mounting slots.


To reassemble—reverse above procedure.



The RGA 12 and RGA 15 are table model radio receivers and the RGD 20 is a table model clock radio designed for the reception of AM broadcasts. These instruments are housed in one piece plastic cabinets with "snap-in" masonite back covers to which is attached the loop antenna and power cord interlock connector. With this mode of power connection, the line cord is disconnected from the chassis thus removing all power when the back cover is removed and the chassis is exposed. The use of captive knobs, which cannot be separated from the cabinet, and line cord disconnect removes the possibility of shock hazard in these instruments.



Chassis Layout—RC-1213A, K (Component side)




Chassis Layout—RC-1213A, K (Wiring side)

RCA VICTOR

Model VGP 72

Chassis RS-216A




(Models VGE-15M, VGP-83 Chassis RS-219A, -B, are similar to this material)

CHASSIS REMOVAL


The top of the record changer compartment comprises the complete chassis. It rests on and is secured to a ledge at the front and is held by screws at the rear. The recommended procedure for its removal is as follows:

1. Remove knobs.
2. Pull record changer drawer down.
3. Remove four (4) plated screws holding front of chassis to horizontal ledge located inside of compartment at front of top.



Printed Wiring Board—View from Wiring Side


RCA Victor Models VGE-03W, VGP-25E, T, VGP-34E, G, VGP-43E, T





CHASSIS ACCESSIBILITY

The "Solid Copper Circuit" transistorized amplifier chassis is physically mounted to the motorboard under the turntable with the large components, such as the transformers and filter capacitors, protruding downward through cutouts in the motorboard. When the turntable is removed, the wiring side of the circuit board is exposed. The output transistors and rectifiers are mounted to the motorboard.

Power connections (B+ and B-) and the output transistors collector connections are made through the four insulated bolts which mount the amplifier chassis to the motorboard. All other connections to the chassis are made by "slip-on" clips.



RCA Victor Models VGP-05A, E, N, VGP-08A, G, N, Y, Chassis RS-225, -A




STYLUS REMOVAL AND REPLACEMENT

The stylus assembly is held to the cartridge either by a screw or by a plastic button.

To remove the stylus when held by a screw—loosen, but do not remove the screw, and slide the stylus assembly out from under it. To replace the stylus—slide the spade end of the stylus assembly under the head of the screw, making certain that it is fully seated, and tighten screw. Check that stylus saddle is seated on the yoke.

To remove the stylus when held by a plastic button—grasp the stylus assembly with a pair of tweezers or needle nose pliers and pull it out from under the plastic button. To replace the stylus—push the spade end of the assembly under the plastic button making certain that it is fully seated. Check that the stylus saddle is seated on the yoke.



Pickup and Stylus Assembly

Chassis RC-1220A

C101.....D1	C126.....B3	C228.....D7	CR401.....E9	R102.....B1	R214.....B3	R404.....A9
C101A.....D1		C229.....B8	CR402.....E9	R103.....C1	R216.....B4	R405.....A8
C101B.....D2	C201.....E4	C231.....B8		R104.....B1	R217.....B4	R406.....B9
C101C.....D2	C202.....E5	C232.....CB	L101.....D1	R106.....C2	R218.....B5	R407.....B9
C101D.....D3	C203.....D4	C233.....B7	L102.....C1	R107.....B2	R219.....B5	R408.....C9
C101E.....D4	C204.....C5	C234.....C6	L103.....C2	R108.....B2	R221.....A5	R409.....D7
C101F.....D4	C206.....E5	C235.....B4	L104.....C2	R109.....A1	R222.....B5	R411.....C8
C102.....C1	C208.....B3	C236.....C5		R111.....B1	R223.....A5	R412.....D8
C103.....C1	C209.....B3	C237.....C6	L201.....A2	R112.....A2	R224.....B6	R413.....D9
C104.....A1	C210.....A2	C238.....C6	L202.....C6	R113.....A2	R226.....B6	R414.....C9
C106.....C1	C211.....A4		L203.....C7	R114.....A2	R227.....A7	R416.....D9
C107.....C1	C212.....B4	C401.....A8		R115.....D2	R228.....B7	R417.....D9
C108.....C2	C213.....B5	C402.....B9	Q101.....C1		R229.....CB	R418.....C9
C109.....C1	C214.....B4	C403.....B9	Q102.....B2	R201.....E4	R231.....C7	R419.....E7
C111.....C2	C215.....B4	C404.....D8		R202.....E4	R232.....C7	
C112.....C3	C216.....A5	C405.....AB	Q201.....E5	R203.....E5	R234.....A8	T101.....E1
C113.....C2	C217.....B5	C406.....D6	Q202.....D5	R204.....D5	R236.....BB	T102.....B2
C114.....B1	C218.....B5	C407.....D9	Q203.....A3	R205.....D5	R237.....BB	
C116.....B2	C219.....A6	C408.....C9	Q204.....A5	R206.....C5	R238.....B8	T201.....D5
C117.....B2	C220.....A3	C409.....D9	Q205.....A6	R207.....C5	R239.....C6	T202.....C4
C118.....C2	C221.....A6	C411.....E9		R208.....D6	R241.....C6	T203.....C3
C119.....C2	C222.....B6		Q401.....A9	R209.....A4	R243.....C6	T205.....B6
C121.....B2	C223.....B7	CR101.....A3	Q402.....B9	R210.....E6		T206.....B6
C122.....B2	C224.....B7	CR201.....B6	Q403.....DB	R211.....B4	R401.....A9	T207.....A7
C123.....B3	C226.....C7	CR202.....BB	Q404.....D9	R212.....B3	R402.....A9	
C124.....B3	C227.....B7	CR203.....B7		R213.....A3	R403.....A9	T401.....C8

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

RCA Victor Chassis RC-1220A, Continued

AM-FM ALIGNMENT PROCEDURE

INSTRUMENTS REQUIRED

Signal Sources

1. RF Signal Generator (RCA WR-50A or equivalent)
2. TV/FM Sweep Generator (RCA WR-69A or equivalent)
3. Marker Generator (RCA WR-99A or equivalent)

Output Indicators

4. Vacuum-Tube Voltmeter (RCA WV-98B or equivalent)
5. Oscilloscope (RCA WO-91A or equivalent)

Tools

6. Hex head alignment tool
7. Thin fibre shaft alignment tool


GENERAL ALIGNMENT CONDITIONS

1. Connect low side of signal source and output indicator to chassis ground as close as possible to high side connection unless otherwise specified.
2. Signal input must be kept as low as possible to avoid AVC action. (Set output indicator to highest sensitivity.)
3. Markers must be accurate. (Crystal controlled or checked against a crystal calibrator.) The 10.7 mc marker used in each section of the FM alignment must be the same. (Generator dial should not be moved.)
4. Marker insertion and amplitude must not distort the oscilloscope trace.
5. Standard modulation is 400 cycle at 30% amplitude.

STEP	Signal Source— Connected to—	Set Signal to—	Set Radio Dial to—	Output Indicator— Connected to—	Adjust	Adjust for—	STEP		
1	Set Radio Function Switch on "AM"						1		
2	RF Generator— Q202 Base through a 0.01 μ f capacitor	455 kc (modulated)	Quiet point on band near 1600 kc	V.T.V.M.— Across speaker voice coil	T206 (3rd AM IF)	Maximum	2		
3					T204 Tap (2nd AM IF)		3		
4					T203 Top & Bottom (1st AM IF)		4		
5	RF Generator— A standard radiating loop or short piece of wire placed near AM antenna	1620 kc (modulated)	gang fully open		C101F-T (Oscillator Trim)		5		
6		1400 kc (modulated)	1400 kc		C101D-T (Antenna Trim)		6		
7					C101E-T (RF Trimmer)		7		
8					T201 (RF Trans.)		8		
9		600 kc (modulated)	600 kc (rack gang)		T202 (Oscillator Coil)		9		
10	Repeat steps 2 through 4 and steps 5 through 9 as necessary to obtain maximum sensitivity on stations						10		
11	Set Radio Function Switch on "FM"						11		
12	RF Generator— Q205 Base through a 0.01 μ f capacitor	10.7 mc (unmodulated)	Quiet point on band	V.T.V.M.— Across R232	T207 Bottom core (Pri.) (Ratio Detector)	Maximum	12		
13				V.T.V.M.— (Set to center zero) Junction of C231, R236, R237	T207 Tap core (Sec.) (Ratio Detector)	Zero Voltage (cross-over)	13		
14	Repeat steps 12 and 13 as necessary to obtain a balanced "S" curve with ± 200 kc linearity						14		
15	TV/FM Sweep Gen.— Q204 Base through a 0.01 μ f capacitor	240 kc Sweep centered at 10.7 mc with markers at 10.6, 10.7 & 10.8 mc	Quiet point on band	Oscilloscope— with signal Tracing Probe (RCA WG-302A)	*Detune T204 Bottom	Maximum symmetrical response centered at 10.7 mc with 10.6 and 10.8 mc at equal heights within 10 % and approx. 40 % down slope (limits between 30 % -60 %)	15		
16	T205 Top & Bottom (3rd FM IF)				16				
17	TV/FM Sweep Gen.— Q203 Base through a 0.01 μ f capacitor			Q205 Base (adjust signal input to obtain a 30 mv P-P reading on oscilloscope)	*Detune T102 Top		17		
18	T204 Bottom (2nd FM IF)				18				
19	TV/FM Sweep Gen.— One FM antenna terminal				T102 Top & Bottom (1st FM IF-in tuner)		19		
20	Repeat steps 15 thru 19 as necessary to obtain specified response						20		
21	Marker Generator— across FM antenna terminals through a matching network if necessary	108.5 mc	gang fully open	V.T.V.M.— Across speaker voice coil	C118 (Oscillator Trimmer)	Maximum	21		
22					C101B-T (RF-Trimmer)		22		
23					C101A-T (Antenna Trimmer)		23		
24	Repeat steps 21, 22 and 23 as necessary to obtain maximum sensitivity on stations						24		

* When detuning T204 & T102, the specified core should be adjusted until no action appears in the trace with further adjustment of the core (2 or more turns). Opposite core will have little or no effect after specified core is fully detuned.


RCA Victor
Chassis RC-1220A
(Continued)



SYMBOL NO.	STOCK NO.	DESCRIPTION
C118	115092	trimmer—1.8 μ f—for C101C
C119	115658	ceramic—12 μ f, $\pm 5\%$, 500 v
C121	115660	mica—220 μ f, $\pm 5\%$, 100 v
C122	115656	ceramic—6 μ f, $\pm 10\%$, 500 v
C123	115091	ceramic—0.01 μ f, $\pm 20\%$, 100 v
C124	115661	mica—150 μ f, $\pm 5\%$, 100 v
C126		ceramic—1500 μ f, $\pm 10\%$, 500 v
C201		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C202		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C203		ceramic—3300 μ f, $\pm 20\%$, 100 v
C204		ceramic—0.01 μ f, $\pm 20\%$, 100 v
C206		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C208		ceramic—0.01 μ f, $\pm 20\%$, 100 v
C209		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C210		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C211		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C212		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C213		ceramic—1000 μ f, $\pm 10\%$, 500 v
C214		ceramic—0.033 μ f, $\pm 20\%$, 100 v
C215		ceramic—2200 μ f, $\pm 10\%$, 500 v
C216		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C217	105310	ceramic—390 μ f, $\pm 10\%$, 500 v
C218	112969	ceramic—0.1 μ f, $\pm 20\%$, 50 v
C219	115666	headed lead—1 μ f, $\pm 5\%$, 500 v
C220		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C221		ceramic—680 μ f, $\pm 10\%$, 500 v
C222		ceramic—680 μ f, $\pm 10\%$, 500 v
C223		ceramic—0.01 μ f, $\pm 100-20\%$, 100 v
C224		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C226		ceramic—330 μ f, $\pm 10\%$, 500 v
C227		ceramic—330 μ f, $\pm 10\%$, 500 v
C228	111370	electrolytic—2 μ f, $\pm 250-10\%$, 50 v
C229		ceramic—330 μ f, $\pm 10\%$, 500 v
C231		ceramic—0.022 μ f, $\pm 20\%$, 100 v
C232		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C233		ceramic—2200 μ f, $\pm 20\%$, 100 v
C234	115100	electrolytic—10 μ f, $\pm 100-10\%$, 10 v
C235		ceramic—0.047 μ f, $\pm 100-20\%$, 100 v
C236	115100	electrolytic—10 μ f, $\pm 100-10\%$, 10 v
C237		mylar—0.1 μ f, $\pm 20\%$, 100 v
C238		ceramic—3300 μ f, $\pm 20\%$, 100 v
C401	115180	electrolytic—1.2 μ f, $\pm 20\%$, 15 v
C402	115803	electrolytic—100 μ f, $\pm 100-10\%$, 15 v
C403	115617	electrolytic—100 μ f, $\pm 250-10\%$, 6 v

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

RCA Victor Chassis RC-1220A Schematic Diagram, Continued




NOTES:

UNLESS OTHERWISE SPECIFIED


1. ALL CAPACITOR VALUES LESS THAN 1.0 ARE μf VALUES 1.0 & ABOVE ARE Pf.
2. ALL RESISTORS 1/2 W & VALUES ARE IN OHMS. K=1000
3. ALL CONNECTORS SHOWN FROM WIRED SIDE.
4. CONNECTOR PIN NUMBERS FOR REF. ONLY.
5. ALL SECTIONS OF SWITCH S1 ARE VIEWED FROM FRONT, WITH SWITCH IN EXTREME C.C.W. POSITION.
6. VOLTAGES MEASURED WITH "VOLTOHMYST" & SHOULD HOLD WITHIN $\pm 20\%$ AT RATED LINE VOLTAGE MEASURED TO CHASSIS GROUND & NO SIGNAL APPLIED.

Dial Cord Arrangement




VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION


RCA Victor Model RHA-39W, Chassis RC-1224C; Model RHD-29W, Chassis RC-1224D




IF 455 KC.






1. ALL RESISTANCE VALUES ARE IN OHMS $\times 1000$
2. CAPACITANCE VALUES LESS THAN 1.0 ARE IN μF , VALUES 1.0 & ABOVE ARE IN μF EXCEPT AS NOTED
3. VOLTAGES MEASURED TO CHASSIS GROUND (JUNCTION OF R21 & R25)
4. LETTERS SHOWN ON LINES INDICATE CONNECTIONS ON PRINTED BOARDS.



C1.....1C	C16.....5C	CR1.....5C	R1.....1A	R17.....4B	R33.....7B
C2.....1A	C17.....5C	CR2.....8A	R2.....1A	R18.....5B	R34.....5B
C3.....1A	C18.....5C		R3.....4C	R19.....4C	R36.....5A
C4.....2A	C19.....6B	FB1.....4C	R4.....2A	R21.....4C	R37.....8B
C6.....3A	C22.....6B		R6.....3A	R22.....6C	R3B.....BC
C7.....2B	C23.....6A	Q1.....1A	R7.....2B	R24.....5B	RV1.....6A
C8.....2C	C24.....6B	Q2.....3A	RB.....3A	R26.....6B	
C9.....2C	C26.....7C	Q3.....3C	R9.....3A	R27.....5A	T1.....2A
C11.....3B	C27.....4B	Q4.....4C	R12.....2C	R28.....5A	T2.....3B
C12.....4B	C28.....4A	Q5.....6B	R13.....4B	R29.....5B	T3.....3B
C13.....4B	C29.....8B	Q6.....7B	R14.....4A	R31.....5B	T4.....4B
C14.....4C	C31.....BA		R16.....4C	R32.....5B	T5.....5B
					T6.....7A



Chassis Layout (Component Side)



NOTES:
1. WIRING DIAGRAM IS SHOWN FROM CIRCUIT SIDE OF BOARD.
2. SOLID LINES INDICATE WIRE JUMPERS

SEARS, ROEBUCK and CO. RADIO CHASSIS No. 528.63131

USED IN MODELS:




6223 6224
6225

TUNER CIRCUIT BOARD DIAGRAM

SEARS, ROEBUCK AND CO.

CHASSIS 132.91301


Used in Models 6208,
6209, 6210, 6211



CIRCUIT BOARD DIAGRAM
(Bottom View)

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

SEARS, ROEBUCK Chassis No. 132.90301, Models 6202, 6203, 6204



CAPACITANCE VALUES LESS THAN 1.0 ARE IN MICROFARADS (μ F), AND VALUES GREATER THAN 1.0 ARE IN PICOFARADS (pF) EXCEPT WHERE NOTED.

VOLTAGE READINGS TO COMMON GROUND (—) ARE MEASURED WITH VACUUM TUBE VOLTMETER UNDER NO SIGNAL CONDITIONS.


RESISTANCE VALUES ARE IN OHMS, K = 1000.

⊕ COMMON GROUND SYMBOL.

⊕ EXTERNAL CONNECTION TO PRINTED CIRCUIT.

TOTAL BATTERY CURRENT DRAIN UNDER NO SIGNAL CONDITIONS .7.5 TO 14.0 MA.

9.0 VOLT BATTERY



PHONE JACK


RED DOT OVER PIN 1

SPKR.



CIRCUIT BOARD DIAGRAM
(Bottom View)



AM IF 455 KC.
FM IF 10.7 MC.




-



VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

SEARS, ROEBUCK & CO. Chassis 528.63140, Model 6200



AM IF 455 KC.
FM IF 10.7 MC.






SONY

TR-830

Schematic Diagram

X5 2SD65 X6 2SD66 X7.8 2SD65


X1 2SC73 X3 2SC76 X4 2SC76



IF 455 KC.

* To be adjusted

X2 2SC76



Mounting Diagram

—Printed Side—


C29 is mounted on the printed side.

Symbol	Description	Symbol	Description
C1-1-2	Tuning Capacitor, 2 gang	R9	470 Ω 1/8W Carbon
C3-1-2	Trimmer Capacitor, 2 unit	R10	10K Ω "
C4	0.02μF Ceramic	R11	39K Ω "
C5	0.002μF Mylar	R12	3.3K Ω "
C6	0.002μF "	R13	470 Ω "
C7	0.01μF Ceramic	R14	1.8K Ω "
C8	130PF Styrol	R15	5K Ω Volume Control
C9	150PF (built in IFT ₁)	R16	36K Ω 1/8W Carbon
C10	10μF 3V Electrolytic	R17	5.6K Ω "
C11	0.02μF Ceramic	R18	1K Ω "
C12	1PF "	R19	1K Ω "
C13	150PF (built in IFT ₂)	R20	27K Ω "
C14	0.01μF Ceramic	R21	10K Ω "
C15	0.01μF "	R22	1K Ω "
C16	150PF (built in IFT ₃)	R23	10 Ω "
C17	0.02μF Ceramic	R24	220 Ω "
C18	0.02μF "	R25	7.5K Ω "
C19	0.01μF "	R26	10 Ω "
C20	0.3μF 15V Electrolytic	R27	680 Ω "
C21	10μF 3V "		
C22	0.005μF Mylar		
C23	10μF 3V Electrolytic		
C24	10μF 6V "		
C25	30μF 3V "		
C26	30μF 10V "		
C27	0.04μF Ceramic		
C28	50μF 10V Electrolytic		
C29	0.02μF Ceramic		

* To be adjusted

SYLVANIA

Chassis U50-1, -2
Models AK45, AK46, AT40



SCHEMATIC NOTES

Line voltage set at 120 volt, 60 cycle.
Voltages shown are average readings measured to chassis ground with no signal, minimum volume setting and variable capacitor fully open.

All capacitors are in microfarads unless otherwise specified.
All resistors are 10%, 1/2 watt unless otherwise specified.
Intermediate frequency (IF), 455 KC.

⊥ designates chassis ground.

Arrow on volume control indicates clockwise direction.




FIGURE A



FIGURE B




FIGURE C

NOTE:
THE CABINET SECTIONS ARE HELD TOGETHER WITH SNAP TABS SHOWN BY ARROWS. SEE FIGURES A AND C.

SYLVANIA

Chassis 325-1, Model TR50




SCHEMATIC NOTES


1. Voltage measured to positive (red) battery connector, with receiver tuned to off station.
2. Operating voltage must be 9 volts DC. (Employ battery eliminator).
3. Voltages shown are average readings. Variations may be noted due to normal production tolerance ($\pm 10\%$).
4. All voltage readings taken with RCA Volt-Ohmmyst (WV - 97A).
5. All capacitors in microfarads unless otherwise specified.
6. Intermediate frequency (IF), 455 KC.
7. Resistance readings taken with components in circuit.

CURRENT DRAIN
NO SIGNAL MIN. VOLUME 7mA DC
STRONG SIGNAL MAX. VOLUME 40mA DC


*SELECTED TO MATCH TRANSISTOR CHARACTERISTICS.
C8 50MFD 10V



— BOTTOM PARTS LAYOUT —




SYLVANIA
Chassis 328-1, Model TR54



SCHEMATIC NOTES

1. Voltage measured to positive (red) battery connector, with receiver tuned to off station.
2. Operating voltage must be 9 volts DC. (Employ battery eliminator).
3. Voltages shown are average readings. Variations may be noted due to normal production tolerance ($\pm 10\%$).
4. All voltage readings taken with RCA Volt-Ohmyst (WV - 97A).
5. All capacitors in microfarads unless otherwise specified.
6. Intermediate frequency (IF), 455 KC.
7. Resistance readings taken with components in circuit.


* SELECTED TO MATCH TRANSISTOR CHARACTERISTICS.



— BOTTOM PARTS LAYOUT —

SYLVANIA

Chassis 335-1, Model TR86




SCHEMATIC NOTES

1. Voltages measured to chassis ground, test point (2), with receiver tuned to off station and minimum volume.
2. Operating voltage must be 6 volts DC. (Employ battery eliminator).
3. Voltages shown are average readings. Voltages in brackets are measured with switch in FM position.
4. Switch SW2 is shown in the AM position.
5. All capacitors in microfarads unless otherwise specified.
6. All resistors are 1/4W - 10% unless otherwise specified.
7. Resistance readings taken with components in circuit.
8. Arrow on volume control indicates clockwise rotation.


CHASSIS REMOVAL

1. Remove three (3) knobs; two (2) front knobs and the one (1) side knob by pulling straight out.
2. Open back cover flap by unsnapping the fasteners at bottom rear of case.
3. Unsnap battery holder and remove from case.
4. Remove two (2) screws securing battery compartment. Remove compartment from case.
5. Remove earphone and ext. pwr. jack assembly from case.
6. Remove six (6) screws (indicated by ⊗ on top parts layout) securing chassis to case. Remove one (1) screw (located on bottom of case) securing telescopic antenna to case.
7. Remove chassis and set to one side of case. If necessary unsolder leads to speaker.
8. To replace chassis reverse the above procedure.




DIAL STRINGING

SYLVANIA Chassis P02-1, Model 45P60





- NOTES:
1. VOLTAGE MEASUREMENTS ARE AVERAGE READINGS MEASURED TO CIRCUIT GROUND.
 2. SEE SCHEMATIC DIAGRAM FOR VOLTAGE READINGS ON POWER OUTPUT TRANSISTORS Q3, Q6.



SYLVANIA


Chassis P03-1
Model 45P61



Westinghouse

CHASSIS V-2463-1, -2

H-954P6
H-955P6
H-956L6
H-957L6
H-958L6




VOLTAGE MEASUREMENTS MADE WITH A VTVM FROM POINTS INDICATED TO GROUND WITH TUNING CAPACITOR AT MAXIMUM. VOLUME CONTROL AT MINIMUM.
ALL CAPACITANCE VALUES LESS THAN 1 ARE IN MF. B VALUES GREATER THAN 1 ARE IN PF.
ALL RESISTANCE VALUES ARE IN OHMS, 1/2 WATT UNLESS OTHERWISE INDICATED.
LATER PRODUCTION R6-470-0

V-2463-1 Schematic


CHASSIS REMOVAL H-954P6, H-955P6

The cabinet front and back are held together by 4 tabs molded on the top and bottom rim of the cabinet back.

1. Pry the bottom of the cabinet apart to release the two bottom tabs and carefully separate the two sections. CAUTION: the battery housing is mounted to the cabinet back.
2. The volume and tuning knobs are mounted to the PC board which comes out with the cabinet front.
3. Unsolder the two leads to the speaker.
4. Remove the hex head screw and mounting stud (located under the PC board) from the cabinet front and slide the chassis to the rear.




V-2463-1 PC Board showing top components in solid outline.



Dial Stringing

Westinghouse

Chassis V-2463-3, Models H-957L6A, H-958L6A, Chassis V-2463-4, used in Model H-957L6B, and Chassis V-2463-6, Models CR525, CR526.





Bottom View of PC Board Showing Top Components In Solid Outline.

Westinghouse

H-970X
H-972XL
H-974XL

CHASSIS V-2463-5




FUNCTION	TRANSISTOR COMPLEMENT
CONVERTER	PNP 297V055C01
1ST IF	PNP 297V054C01
2ND IF	PNP 297V054C02
AUDIO DRIVER	PNP 297V052C01
AUDIO OUTPUT	PNP 297V053C01
SWITCHED PAIR	

Westinghouse


Chassis V-2466-1, -2, used in Models H-200T5, H-201T5, H-205L5, H-210L5, H-211L5, H-215L5, H-216L5, CR-500, and CR-501.

Chassis V-2466-7 used in Models CR-515, CR-520, CR-521, is identical except for clock circuit.




CHASSIS REMOVAL

1. Remove the back cover.
2. Remove the volume knob.
3. Release the tuning knob from the tuning capacitor. CAUTION: The tuning knob is captivated to the cabinet front.
4. Lift the PC board at the rear, to clear the square bar on the cabinet bottom, and slide the chassis to the rear.
5. It may be necessary to unsolder the leads from the clock and speaker before the chassis can be completely removed from the chassis.
6. To reassemble the chassis to the cabinet, reverse the above procedure. It may be necessary to force the front edge of the PC board down into the mounting slots provided in the cabinet front. This can be accomplished by applying pressure to the electrolytic.



H-215L5 - H-216L5




Bottom View of PC Board showing top components in solid outline.

Westinghouse

MODEL
CR-566MODEL
H-953XP8


CHASSIS V-2580-1





NOTES:

1. BATTERY DRAIN SHOULD BE MEASURED, WITH NO SIGNAL AND VOL. CONTROL AT MINIMUM. CURRENT DRAIN SHOULD BE APPROX. 15 MA. SW2 IN BATTERY POSITION.
2. ALL CAPACITANCE VALUES LESS THAN 1 ARE IN PF, AND VALUES GREATER THAN 1 ARE IN MF, UNLESS OTHERWISE INDICATED.
3. VOLTAGE MEASUREMENTS MADE WITH V.T.V.M. FROM POINTS INDICATED TO GROUND, WITH TUNING CAPACITOR AT MAX. VOLUME CONTROL AT MIN TWO SIGNAL INPUTS. VOLTAGE SOURCE AT 6 VOLTS.
4. UNDERLINED VOLTAGES TAKEN WITH SW2 IN AC POSITION.

* BIAS CONTROL




TRANSISTOR COMPLEMENT		
Q1	FUNCTION	W. PART NO.
Q1	RF AMP	690V047H54
Q2	CONVERTER	690V047H55
Q3	1ST IF AMP	690V047H56
Q4	2ND IF AMP	690V047H57
Q5	1ST AUDIO	690V047H58
Q6	AUDIO DRIVER	690V047H58
Q7	AUDIO OUTPUT *	690V047H60
Q8	AUDIO OUTPUT *	690V047H60
	* MATCHED PAIR	



SPECIFICATIONS

AM Frequency Range 540KC to 1600KC
 AM Intermediate Frequency 455KC
 Power Output, Maximum 300mw
 Speaker 4" PM, 4-ohm voice coil
 No-Signal Current Drain 15ma





Bottom view of chassis.


Westinghouse

H-968PL

CHASSIS V-2585-1



05
AUDIO OUTPUT



IF 455 KC.



TOP VIEW
OF TRANSISTOR

NOTES:

1. VOLTAGE MEASUREMENTS MADE WITH VTVM FROM POINTS INDICATED TO GROUND. VOLUME CONTROL AT MINIMUM.
2. UNLESS OTHERWISE INDICATED, ALL CAPACITANCE VALUES LESS THAN ONE ARE IN MF AND VALUES GREATER THAN ONE ARE IN PF (PICOFARADS). ALL RESISTANCE VALUES ARE IN OHMS, 1/2 WATT.
3. DURING SERVICING, TOTAL BATTERY CURRENT SHOULD BE MEASURED WITH NO SIGNAL AND VOLUME CONTROL AT MINIMUM. TOTAL BATTERY DRAIN SHOULD BE 6.6 MA. APPROX.

TRANSISTOR COMPLEMENT


FUNCTION	TYPE	W	PART NUMBER	ALTERNATES
Q1 CONVERTER	PNP		680V056H89	
Q2 1ST IF AMP	PNP		680V056H89	
Q3 2ND IF AMP	PNP		680V056H89	
Q4 DRIVER	PNP		680V056H89	
Q5 05.06 AUDIO OUTPUT	PNP		680V056H90	

*-MATCHED PAIR


Westinghouse

H-707P6GPA

CHASSIS V-2461-2



NOTE: C14, C16 & R7 MOUNTED ON OPPOSITE SIDE. (SEE BOTTOM VIEW)




Bottom View of
PC Board Showing Top
Components in Solid Outline.

Westinghouse

H-75AC1E (slate gray)
H-75AC2E (metallic mocha)
H-114AC1 (charcoal blue)

CHASSIS V-2538-2




NOTES:

1. VOLTAGE MEASUREMENTS MADE WITH A VTVM FROM POINTS INDICATED TO B- WITH VOLUME CONTROL AT MINIMUM, LINE VOLTAGE AT 120 VAC.
2. UNLESS OTHERWISE INDICATED: ALL CAPACITANCE VALUES LESS THAN ONE ARE IN MICROFARADS AND VALUES GREATER THAN ONE ARE IN PICOFARADS, ALL RESISTANCE ARE IN OHMS 1/2 WATTS.

WESTINGHOUSE

Models H-127ACS1, H-127ACS6



Chassis V-2539-1



ZENITH RADIO CORPORATION

MODELS M860 & M875


CHASSIS 4LT20Z2 & 4LT21Z2




- NOTES:
1. I.F. TRANSFORMER NUMBERING STARTS WITH #1 TERMINAL AS FIRST TERMINAL COUNTERWISE FROM MARKER CODE TERMINAL AS VIEWED FROM BOTTOM OF CHASSIS.
 2. I.F. FREQUENCY 455 KC
 3. TUNING RANGE 535 - 1620 KC
 4. ALL RESISTORS $\pm 5\%$ TOLERANCE, 1/2 WATT, CARBON UNLESS OTHERWISE SPECIFIED.
 5. RESISTANCE VALUES IN OHMS, CAPACITANCE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
 6. ALL VOLTAGES ARE D.C. UNLESS OTHERWISE SPECIFIED.
 7. D.C. VOLTAGES SHOWN ARE MEASURED WITH NO SIGNAL USING A VACUUM TUBE VOLTMETER.
 8. VOLTAGE MEASURED FROM: GND ON VOLUME CONTROL INDICATES COUNTERCLOCKWISE ROTATION.

ZENITH RADIO CORPORATION

MODELS M507B,C,W AND M511C,W,V USING CHASSIS 5M03





* ALTERNATE PARTS WHEN A1 IS NOT USED SEE SCHEMATIC BELOW



T2-2ND I.F. TRANSFORMER
L5 PRIMARY BOTTOM
L6 SECONDARY TOP

T1-1ST I.F. TRANSFORMER
L3 PRIMARY BOTTOM
L4 SECONDARY TOP





ALIGNMENT PROCEDURE

OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3,L4,L5,L6	Align I.F. for max. output.
2	One Turn Loop Coupled Loosely to Wave magnet	-	1600 Kc.	1600 Kc.	C1D	Set Osc. to Dial Scale.
3		-	1400 Kc.	1400 Kc.	C1B	Align Antenna Stage.

ZENITH RADIO CORPORATION


MODELS T315B, W & P CHASSIS 5M06



Alignment Procedure

OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3, 4, 5, 6	For I.F. Alignment.
2	One Turn Loop Coupled Loosely to Wave Magnet	—	1600 Kc.	1600 Kc.	CID	Set Oscillator to Dial Scale
3		—	1400 Kc.	1400 Kc.	CIB	Align Antenna Stage

ZENITH RADIO MODELS M504C, L & W USING CHASSIS 5M04, MODELS M506C, P & W USING CHASSIS 5M02 AND MODELS M508B, C, L & W USING CHASSIS 5M05



TUBE & TRIMMER LAYOUT CHASSIS 5M04

NOTES:


ALL VOLTAGES MEASURED FROM CHASSIS TO POINTS INDICATED WITH A VACUUM TUBE VOLTMETER HAVING 11 MEGOHMS INPUT RESISTANCE.
 USE ONLY ZENITH NON-INDUCTIVE ELECTROLYTIC CONDENSERS FOR REPLACEMENT.
 IF ANY OTHER TYPE OF ELECTROLYTIC IS USED IT WILL BE NECESSARY TO ADD C6 SHOWN IN DOTTED LINES.
 I.F. TRANSFORMER NUMBERING STARTS WITH #1 TERMINAL AS FIRST TERMINAL CLOCKWISE FROM MARKER CODE TERMINAL AS VIEWED FROM BOTTOM OF CHASSIS.
 I.F. FREQUENCY 455 KC
 TUNING RANGE 535 - 1620 KC
 ALL RESISTORS ±20% TOLERANCE. 1/2 WATT, CARBON UNLESS OTHERWISE SPECIFIED.

DENOTES CHASSIS

ALIGNMENT PROCEDURE


OPER.	CONNECT OSCILLATOR TO	DUMMY ANT.	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3,L4,L5,L6	Align I.F. for max. output.
2	One Turn Loop	—	1600 Kc.	1600 Kc.	C1D	Set Osc. to Dial Scale.
3	Coupled Loosely to Wave magnet	—	1400 Kc.	1400 Kc.	C1B	Align Antenna Stage

ON UI SECTION LEADS LINE UP ACCORDING TO THE PART NO AS SHOWN




ZENITH RADIO CORPORATION

MODELS M512B, C & W CHASSIS 5M13




ZENITH RADIO MODELS N511C,L,W-N513B,J,W-N514C,G,L USING CHASSIS 5N02




NOTE
I.F. TRANSFORMER CORE POSITIONS
ARE AS FOLLOWS
PRIMARY - BOTTOM
SECONDARY - TOP

TUBE POSITIONING GUIDE



NOTES:
ALL VOLTAGES MEASURED FROM CHASSIS TO POINTS INDICATED WITH
AN A.C., D.C. OR VACUUM TUBE VOLT-METER.
USE ONLY ZENITH NON-INDUCTIVE ELECTROLYTIC CONDENSERS FOR
REPLACEMENT.
IF ANY OTHER TYPE OF ELECTROLYTIC IS USED IT WILL BE NECESSARY
TO ADD C6 SHOWN IN DOTTED LINES.
I.F. TRANSFORMER NUMBERING STARTS WITH #1 TERMINAL AS FIRST
TERMINAL CLOCKWISE FROM MARKER CODE TERMINAL AS VIEWED FROM BOTTOM
OF CHASSIS.
I.F. FREQUENCY 455 KC
TUNING RANGE 535 - 1620 KC
ALL RESISTORS .20% TOLERANCE, 1/2 WATT, CARBON UNLESS OTHERWISE
SPECIFIED.
DENOTES CHASSIS

* ALTERNATE PARTS WHEN A1 IS
NOT USED SEE SCHEMATIC
BELOW




ALIGNMENT PROCEDURE


OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	5 Mfd.	455 Kc.	600 Kc.	L3,L4,L5,L6	Align I.F. for max. output.
2	One Turn Loop Coupled Loosely to Wave magnet	—	1600 Kc.	1600 Kc.	C1D	Set Osc. to Dial Scale.
3		—	1400 Kc.	1400 Kc.	C1B	Align Antenna Stage.

ZENITH RADIO CORPORATION

MODELS N506C, L & W - N508B, L & W USING CHASSIS 5N03



* ALTERNATE PARTS WHEN A1 IS NOT USED SEE SCHEMATIC BELOW




ALIGNMENT PROCEDURE


OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3,4,5,6	For I.F. Alignment.
2	One Turn Loop Coupled Loosely to Wave Magnet	—	1600 Kc.	1600 Kc.	CID	Set Oscillator to Dial Scale
3		—	1400 Kc.	1400 Kc.	CIB	Align Antenne Stage

ZENITH RADIO CORPORATION

MODELS N516J, L & W USING CHASSIS 5N09 AND MODELS N519C, J, L, & W USING CHASSIS 5N07




NOTES:
ALL VOLTAGES ARE O.C. UNLESS OTHERWISE SPECIFIED.
ALL VOLTAGES MEASURED FROM CHASSIS TO POINTS INDICATED WITH A VACUUM TUBE VOLTMETER.
USE ONLY ZENITH NON-INDUCTIVE ELECTROLYTIC CONDENSERS FOR REPLACEMENT.
IF ANY OTHER TYPE OF ELECTROLYTIC IS USED IT WILL BE NECESSARY TO ADD C6 SHOWN IN DOTTED LINES.
I.F. TRANSFORMER NUMBERING STARTS WITH #1 TERMINAL AS FIRST TERMINAL CLOCKWISE FROM MARKER CODE TERMINAL AS VIEWED FROM BOTTOM OF CHASSIS.
I.F. FREQUENCY 455 KC
TUNING RANGE 535 - 1620 KC
ALL RESISTORS .20% TOLERANCE, 1/2 WATT, CARBON UNLESS OTHERWISE SPECIFIED.
ALL CAPACITOR VALUE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
DENOTES CHASSIS



ALIGNMENT PROCEDURE




OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3, L4, L5, L6	Align I.F. for max. output.
2	One Turn Loop	-	1600 Kc.	1600 Kc.	CID	Set Osc. to Dial Scale.
3	Coupled Loosely to Wave magnet	-	1400 Kc.	1400 Kc.	CIB	Align Antenna Stage.

DIAL CORD DRIVE SHOWN IN COUNTERCLOCKWISE POSITION



ZENITH RADIO CORPORATION

MODELS N509C, F & W CHASSIS 5N13 AND N512A, H & J CHASSIS 5N12









ALIGNMENT PROCEDURE

OPERATION	CONNECT OSCILLATOR TO	DUMMY ANTENNA	INPUT SIG. FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc.	L3, L4, L5, L6	Align I.F. for max. output.
2	One Turn Loop Coupled Loosely to Wave magnet	-	1600 Kc.	1600 Kc.	C1D	Set Osc. to Dial Scale.
3		-	1400 Kc.	1400 Kc.	C1B	Align Antenna Stage.




ZENITH RADIO CORPORATION MODELS N615C, L & W CHASSIS 6N05



ALIGNMENT PROCEDURE

Operation	Connect Oscillator To	Dummy Antenna	Input Sig. Frequency	Set Dial At	Trimmers	Purpose
1	Converter Grid	.5 Mfd.	455 Kc.	600 Kc	L4, L5, L6, L7	For I.F. Alignment.
2	One Turn Loop Coupled	—	1600 Kc.	1600 Kc.	C1F	Set Oscillator to Dial Scale
3	Loosely to Wave Magnet	—	1400 Kc.	1400 Kc.	C1D, C1B	Align Detector and Antenna Stage

ZENITH RADIO CORPORATION
MODEL M729A CHASSIS 7M03




NOTES:
ARROWS ON CONTROLS INDICATE CLOCKWISE ROTATION.
ALL RESISTORS ARE $\pm 20\%$ TOLERANCE, 1/2 WATT, CARBON UNLESS OTHERWISE SPECIFIED.
ALL VOLTAGES ARE @ C. UNLESS OTHERWISE SPECIFIED.
ALL VOLTAGES ARE MEASURED FROM POINTS INDICATED TO CHASSIS


REMOTE CHASSIS
 THESE VOLTAGES MEASURED IN THE F.M. POSITION.
 F. FREQUENCY: FM 88-108 MC
 AM 540-1620 KC
 DURING RANGE: FM 88-108 MC
 AM 540-1620 KC
 ALL CAPACITOR VALUES IN MICROFARADS AND .2205
 TOLERANCE UNLESS OTHERWISE SPECIFIED

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

ZENITH RADIO Model M730W, Chassis 7M04



MODEL ROYAL 710M ALL TRANSISTOR PORTABLE RADIO CHASSIS 7MT44Z2




ALIGNMENT PROCEDURE


Operation	Input Signal Frequency	Connect Inner Conductor From Oscillator To	Connect Outer Shield Conductor From Oscillator To	Set Dial At	Trimmers	Purpose
1	455 KC	ONE TURN LOOSELY COUPLED TO WAVEMAGNET	Chassis	600 KC	Adj. T1, T2, T3 for maximum output.	For I.F. Alignment
2	1620 KC			Gong wide open	C1C	Set oscillator to dial scale.
3	600 KC			Set dial near 600 KC	Adjust slug in T6	Adjust T6 for maximum output while rocking gong. Adjust for maximum output regardless of dial accuracy.
4	REPEAT STEPS 2 & 3					
5	1260 KC			1200 KC	C1A	Align loop ant.

ZENITH RADIO
Model "Royal 705M"
Chassis 7MT45Z8, 7MT45Z9

ZENITH RADIO
Model "Royal 705M"
Chassis 7MT45Z8, 7MT45Z9




ZENITH RADIO Model "Royal 755M" Chassis 8MT41Z2




ZENITH RADIO

Model "Royal 180"

Chassis 8MT50Z8, 8MT50Z9



ZENITH RADIO Model "Royal 80" Chassis 8MT51Z8 and 8MT51Z9



ZENITH RADIO Model "Royal 80"
Chassis 8MT51Z8 and 8MT51Z9


TRANSISTOR AND TRIMMER LAYOUT
CHASSIS 8MT51Z9

TRANSISTOR AND TRIMMER LAYOUT
CHASSIS 8MT51Z8



ZENITH RADIO CORPORATION

MODEL SA55




NOTES:

1. RESISTORS ARE 1/2 WATT $\pm 10\%$ TOLERANCE UNLESS OTHERWISE SPECIFIED.
2. OBSERVE POLARITIES OF CAPACITORS.
3. * INDICATES RED DOT ON SPEAKERS.

SPECIFICATIONS

Power Supply.....120V AC 60 Cycles
 Current Consumption.....27 Watts
 Peak Power Output.....4 Watts per channel
 Speakers.....Two 4" PM, 16 ohm V.C.
Two 5 1/4" PM, 16 ohm V.C.



INDEX

Under each manufacturer's name are listed that make chassis and models in numerical order, at left. The corresponding page number at right of each listing refers to the first page of each section dealing with such material.

<u>Admiral Corp.</u>	<u>Admiral, Cont.</u>	<u>Emerson, Cont.</u>	<u>Magnavox</u>	<u>Motorola +</u>
2B2 6	YG1531 11	32P07, A 27	R252 39	AT31B 69
4E4 11	YG1571 7	32P09 28	A505 41	AC40A 45
4F4 20	SMG2201 7	32P10 28	AM-802 40	AC43B 69
5V6, A 12	SRG2201 7	32P11 28		X58 51
5W6 12	SMG2205 7	32P12 27	<u>Matsushita</u>	X60 47
8A4 15	SMG3001 7	120789 22	RE-124 42	X61 52
8B4 16	SMG3002 7	120791 21		X62 50
8F3 4	SMG3701 7	120792 21	<u>Montgomery</u>	X64 54
8K4 3	SMG3705 7	120793 21	<u>Ward</u>	X65 48
8L3, A 20	SMG3711 7	120794 21	GEN-1336A 43	XP68B 55
10A2 17	YG8001, M 7	120795 26	GEN-1808A 44	XP69B 56
10J1 5	YG8002, M 7	120796 26	GEN-1837A 44	XP73B 57
12B2 18	YG8011, M 7	120797 26	GEN-1847A 44	MP100B 89
12H1 14	YG8012, M 7	120798 26	GEN-1857A 44	PP200B 88
20C5, A 7	YG8025, M 7	120818 24	GEN-1877A 44	PP201B 88
22C5, A 7	YG8031, M 7	120819 24	GEN-1897A 44	232 72
YG171 14	YG8045, M 7	120826 21		233 72
YD201GP, A 3	YG8051, M 7	120828 21	<u>Motorola</u>	235S 72
YD202GP, A 3	YG8061, M 7	120832 27	XP1C 63	TM295M 74
YD242 4	YG8075, M 7	120833 27	XP2C 68	TM296M 76
YD243 4	YG8201 18	120836 28	XT2B 59	PP301B 90
YD257 5	YG8215 18		XP3C 64	PP302B 90
YH301GP 15	YG8229 18		XT3B 59	SP310B 90
YH302GP 15			AC4B 69	TM316M 78
YH312 16		<u>General</u>	AC5B 45	TM325M 80
YH313 16	<u>Emerson Radio</u>	<u>Electric</u>	TM5A 70	TM326M 82
YH321 17	31L7 22	T2AB 38	BC6A 62	TM336M 84
YG411 18	31L8 22	TU50 35	TC7B 60	PK400B 90
TM441 18	31L09 21	TU500 35	XP7C 66	PK401B 90
PA451 20	31L10 21	P740A 31	TC8B 60	SK450B 90
PS461 20	31L11 21	P741A 31	BC9B 62	SK451B 90
YG827 12	31T09 21	P780H 30	XC11B 59	SK452B 90
YG829 12	31T10 21	P891A 29	XC12B 59	SK453B 90
YG837 12	31T11 21	P915E 31	BT13A 62	SK500B
YG839 12	31L12 24	P916E 31	XC13B 59	through
YG841 12	31L13 24	P917E 31	TT14B 60	SK509B 90
YG851 12	31L14 24	P955E 32	TT15B 60	TM526A 86
YG861 12	31L15 26	C1410A 33	XC14B 59	HS-2334 90
YG1027 6	31L17 26	C1411A 33	BT16B 62	HS-2336 90
YG1029 6	31T12 24	C1412A 33	23LK412B 90	HS-2339 90
YG1037 6	31T13 24	P1700A 34	23LK413B 90	HS-2347 88
YG1047 6	31T15 26	P1701A 34	23LK414B 90	HS-2348 89
YG1057 6	31T17 26	P1704A 34	23LK415B 90	HS-2349 90
YG1507 11	32P01A 27	P9151E 31	23LK416B 90	HS-4143 46
YG1527 11	32P06, A 27	P9161E 31	AT23A 46	HS-4152 45
		P9171E 31	AT30B 69	HS-6127 47

(Index continued on page 176)

VOLUME R-26, MOST-OFTEN-NEEDED 1966 RADIO SERVICING INFORMATION

INDEX Continued

Motorola +	Philco, Cont.	RCA, Cont.	Westinghouse	Zenith, Cont.
HS-6131 50	P1719 104	RC-1213W 111	H-75AC1E 151	5M05 156
HS-6133 48	P1722 104	RC-1219A 112	H-75AC2E 151	5M06 155
HS-6136 51	P1735 104	RC-1219B 112	H-114AC1 151	5M13 157
HS-6137 52	P1737 104	RC-1219D 113	H-127ACS1 151	5N02 158
HS-6139 54		RC-1220A 124	H-127ACS6 151	5N03 159
HS-6202 55		RC-1221A 114	H-200T5 147	5N07 160
HS-6207 56	<u>RCA Victor</u>	RC-1221B 115	H-201T5 147	5N09 160
HS-6208 57	VGE-03W 122	RC-1222A 116	H-205L5 147	5N12 161
HS-7201 59	VGP-05A,+ 123	RC-1224 118	H-210L5 147	5N13 161
HS-8201 62	VGP-08A,+ 123	RC-1224C 128	H-211L5 147	6N03 162
HS-8202 62	RGH-10 119	RC-1224D 128	H-215L5 147	6N05 163
HS-8206 60	RGA-12Y 120		H-216L5 147	7M03 164
HS-8207 60	RGH-12 116	<u>Sears, Roebuck</u>	CR-500 147	7M04 165
HS-66200 63	RHA-12G,+ 111	6055 132	CR-501 147	7MT44Z2 166
HS-66201 68	RHD-13N,Y 111	6056 132	CR-515 147	7MT45Z8 167
HS-66202 64	RGA-15A,+ 120	6200 134	CR-520 147	7MT45Z9 167
HS-66206 66	VGE-15M 121	6202 131	CR-521 147	8MT41Z2 168
HS-67201 69	RGG-17B 112	6203 131	CR-525 145	8MT50Z8 169
HS-68202 69	RHA-17A,+ 111	6204 131	CR-526 145	8MT50Z9 169
	RHD-17A,+ 111	6208 130	CR-566 148	8MT51Z8 170
<u>Panasonic</u>	RHH-17 117	6209 130	H-707P6+ 150	8MT51Z9 170
RE-124 42	RGD-20N,+ 120	6210 130	H-953XP8 148	8MT52Z8 171
	RHD-21A,+ 111	6211 130	H-954P6 144	8MT52Z9 171
<u>Philco Corp.</u>	RHG-21 113	6223 129	H-955P6 144	8NT04 174
P10ST 100	RGG-22A,+ 112	6224 129	H-956L6 144	SA55 172
P25ST 104	RGG-25B,+ 112	6225 129	H-957L6 144	59 171
P710 97	RHG-25 113	132.90301 131	H-957L6A 145	80 170
P720 96	VGP-25E,T 122	132.91301 130	H-957L6B 145	MPS 90 173
P721 96	RGA-27 111	528.63131 129	H-958L6 144	180 169
P722 96	RGG-29E 114	528.63140 134	H-958L6A 145	T305C,+ 153
P723 96	RHC-29W 124	528.63470 132	H-968PL 149	T315B,+ 155
P724 96	RHD-29W 128	528.63471 132	H-970X 146	M504C,+ 156
NT809 95	RGD-30 111		H-972XL 146	M506C,+ 156
NT814 98	RHG-30E 115	<u>Sony</u>	H-974XL 146	N506C,+ 159
NT815 99	RHC-33W 124	TR-8 135	V-2461-2 150	M507B,+ 154
P880 96	VGP-34E,G 122	TR-830 136	V-2463-1 144	M508B,+ 156
P881 96	RHC-37L 124		V-2463-2 144	N508B 159
P882 96	RGA-39W 118	<u>Sylvania</u>	V-2463-3 145	N509C,+ 161
P883 96	RHA-39W 128	P01-1 141	V-2463-4 145	M511C,+ 154
P884 96	RGA-40W 118	P02-1 142	V-2463-5 146	N511C,+ 158
P885 96	RHC-41W 124	P03-1 143	V-2463-6 145	M512B,+ 157
P933 97	VGP-43E,T 122	AT40 137	V-2466-1 147	N512A 161
P941 97	RHC-45F 124	45P50 141	V-2466-7 147	N513B,+ 158
P1002 100	RHC-49S 124	45P60 142	V-2538-2 151	N514C,+ 158
P1441 106	VGP-72 121	45P61 143	V-2539-1 151	N516J,+ 160
P1442 106	RS-216A 121	AK45 137	V-2580-1 148	N519C,+ 160
P1444 107	RS-219A,B 121	AK46 137	V-2585-1 149	N615C,+ 163
P1445 108	RS-225,A 123	TR50 138	<u>Zenith Radio</u>	N624A,+ 162
P1446 108	RC-1213A 120	U50-1,-2 137	4LT20Z2 152	705M 167
P1511 109	RC-1213AA 111	TR54 139	4LT21Z2 152	710M 166
P1513 110	RC-1213AB 111	TR86 140	5M02 153	M729A 164
P1515 110	RC-1213K 120	325-1 138	and 156	M730W 165
P1710 104	RC-1213M 111	328-1 139	5M03 154	755M 168
P1718 100	RC-1213R 111	335-1 140	5M04 156	M860 152
				M875 152